



# SIM7600 Series\_Open Linux\_Development Guide

LTE Module

## **SIMCom Wireless Solutions Limited**

Building B, SIM Technology Building, No.633, Jinzhong Road  
Changning District, Shanghai P.R. China

Tel: 86-21-31575100

[support@simcom.com](mailto:support@simcom.com)

[www.simcom.com](http://www.simcom.com)

<b>Document Title:</b>	SIM7600 Series_Open Linux_Development Guide
<b>Version:</b>	2.00
<b>Date:</b>	2020.8.6
<b>Status:</b>	Released

## GENERAL NOTES

SIMCOM OFFERS THIS INFORMATION AS A SERVICE TO ITS CUSTOMERS, TO SUPPORT APPLICATION AND ENGINEERING EFFORTS THAT USE THE PRODUCTS DESIGNED BY SIMCOM. THE INFORMATION PROVIDED IS BASED UPON REQUIREMENTS SPECIFICALLY PROVIDED TO SIMCOM BY THE CUSTOMERS. SIMCOM HAS NOT UNDERTAKEN ANY INDEPENDENT SEARCH FOR ADDITIONAL RELEVANT INFORMATION, INCLUDING ANY INFORMATION THAT MAY BE IN THE CUSTOMER'S POSSESSION. FURTHERMORE, SYSTEM VALIDATION OF THIS PRODUCT DESIGNED BY SIMCOM WITHIN A LARGER ELECTRONIC SYSTEM REMAINS THE RESPONSIBILITY OF THE CUSTOMER OR THE CUSTOMER'S SYSTEM INTEGRATOR. ALL SPECIFICATIONS SUPPLIED HEREIN ARE SUBJECT TO CHANGE.

## COPYRIGHT

THIS DOCUMENT CONTAINS PROPRIETARY TECHNICAL INFORMATION WHICH IS THE PROPERTY OF SIMCOM WIRELESS SOLUTIONS LIMITED. COPYING, TO OTHERS AND USING THIS DOCUMENT, ARE FORBIDDEN WITHOUT EXPRESS AUTHORITY BY SIMCOM. OFFENDERS ARE LIABLE TO THE PAYMENT OF INDEMNIFICATIONS. ALL RIGHTS RESERVED BY SIMCOM IN THE PROPRIETARY TECHNICAL INFORMATION, INCLUDING BUT NOT LIMITED TO REGISTRATION GRANTING OF A PATENT, A UTILITY MODEL OR DESIGN. ALL SPECIFICATION SUPPLIED HEREIN ARE SUBJECT TO CHANGE WITHOUT NOTICE AT ANY TIME.

### **SIMCom Wireless Solutions Limited**

Building B, SIM Technology Building, No.633 Jinzhong Road, Changning District, Shanghai P.R. China

Tel: +86 21 31575100

Email: [simcom@simcom.com](mailto:simcom@simcom.com)

### **For more information, please visit:**

<https://www.simcom.com/download/list-863-en.html>

### **For technical support, or to report documentation errors, please visit:**

<https://www.simcom.com/ask/> or email to: [support@simcom.com](mailto:support@simcom.com)

## Version History

Version	Date	Owner	What is new
V2.00	2019.04.01		Update document format

SIMCom  
Confidential

## This document applies to the following products

The document just applies for SIM7600E-H/SIM7600SA-H series

SIMCom  
Confidential

# Contents

<b>Version History</b> .....	<b>3</b>
<b>This document applies to the following products</b> .....	<b>4</b>
<b>Contents</b> .....	<b>5</b>
<b>Abbreviation</b> .....	<b>10</b>
<b>1 SIM7600 Development Platform Overview</b> .....	<b>11</b>
1.1 System Overview.....	11
1.2 Open Linux selection and function.....	12
1.3 Open Linux related PIN definition.....	13
<b>2. The environment of Open Linux</b> .....	<b>16</b>
2.1 Install Windows Embedded Compiler.....	16
2.1.1 Install ARM GNU/LINUX.....	16
2.1.2 Install Cygwin.....	18
2.2 Configure the Linux compilation environment.....	19
2.2.1 Compilation method.....	19
2.2.2 Making OTA upgrade package command.....	21
2.3 Install Windows driver.....	22
2.4 Debug download tool.....	23
2.5 Application Compilation and Run.....	25
2.5.1 Demo application.....	25
2.5.2 Helloworld application.....	27
2.6 System partition and file protection.....	27
2.7 Production line production mode.....	28
2.7.1 Download APP separately.....	28
2.7.2 Download the compiled image.....	29
<b>3. Programming Guide</b> .....	<b>30</b>
3.1 System basic API.....	30
3.2 Embedded AT transceiver.....	30
3.2.1 Send AT command interface.....	30
3.3 UART.....	30
3.4 GPIO.....	31
3.5 ADC.....	34
3.6 I2C.....	34
3.6.1 Write I2C interface.....	34
3.6.2 Read I2C interface.....	34
3.7 SD Card/EMMC flash.....	35
3.7.1 Partition.....	35
3.7.2 Format.....	35

3.7.3	Mount.....	35
3.7.4	CFDISK Command.....	35
3.8	UIM.....	37
3.8.1	Check SIM card status.....	37
3.8.2	Query SIM card ICCID.....	37
3.8.3	Query SIM card IMSI.....	38
3.9	SMS.....	38
3.9.1	SMS initialization.....	38
3.9.2	Set receive SMS format.....	38
3.9.3	Send messages.....	39
3.9.4	Callback function handles message reception.....	39
3.10	Voice Call.....	40
3.10.1	Phone initialization.....	40
3.10.2	Dial number.....	40
3.10.3	Handle current call.....	40
3.10.4	Get the status of the specified call.....	41
3.10.5	Get all call states.....	41
3.10.6	Callback.....	42
3.11	NAS.....	42
3.11.1	Query registration network status.....	43
3.11.2	Query signal.....	44
3.12	WDS.....	44
3.12.1	Query APN.....	44
3.12.2	Set APN.....	44
3.13	Data Call.....	45
3.13.1	Initialize the network.....	45
3.13.2	Create data link.....	45
3.13.3	Get data link parameters.....	46
3.13.4	Release network resources.....	46
3.14	GNSS.....	46
3.14.1	Initialize gnss.....	47
3.14.2	EnableXTRA.....	47
3.14.3	Prohibit XTRA.....	47
3.14.4	GNSS Cold Start.....	47
3.14.5	GNSS Hot Start.....	48
3.14.6	GPS Stop.....	48
3.14.7	Callback function output brief location information.....	48
3.14.8	Callback function output NMEA statement.....	49
3.15	WIFI.....	49
3.15.1	Get current WIFI mode settings (for W58).....	50
3.15.2	Set WIFI mode (for W58).....	50
3.15.3	WIFI Power.....	51
3.15.4	Get WIFI status.....	51
3.15.5	Set WIFI hotspot name.....	51
3.15.6	Get WIFI hotspot name.....	52

3.15.7	Set AP auth type, encrypt mode, password.....	52
3.15.8	Get AP auth type, encrypt mode, password.....	53
3.15.9	Set up WIFI broadcast switch.....	53
3.15.10	Get WIFI broadcast settings.....	54
3.15.11	Get DHCP settings.....	54
3.15.12	Get the number of connected clients.....	54
3.15.13	Get IP Address in STA Mode.....	55
3.15.14	Get WIFI MACaddress.....	55
3.15.15	Set IP obtained after the STA connects to the external hotspot.....	55
3.15.16	SetSTA's SSID and Password for Connecting to an External AP.....	56
3.15.17	Get SSID and password set by the STA.....	56
3.15.18	WIFI sta Scan available hotspots.....	56
3.15.19	Set username and password for dialing in cdma mode.....	57
3.15.20	Get username and passwordfor dialing in cdma mode.....	57
3.15.21	Get network status.....	57
3.15.22	Restore wifi settings.....	57
3.15.23	Set hotspot name, auth type, encrypt mode, password.....	58
3.15.24	Open/close STA mode (for W58L).....	58
3.15.25	Get the state of STA mode (for W58L).....	59
3.15.26	Get the operation result code.....	59
3.15.27	Description of STA-AP function.....	59
3.15.28	Description of AP-AP function.....	60
3.16	SPI.....	61
3.17	USB OTG.....	61
3.18	Bluetooth.....	61
3.18.1	Bluetooth interface initialization.....	63
3.18.2	Bluetooth power.....	64
3.18.3	Get paired list.....	64
3.18.4	Search Bluetooth.....	64
3.18.5	Bluetooth pairing.....	65
3.18.6	Pairing confirmation request.....	65
3.18.7	Accept pairing.....	65
3.18.8	Pairing results.....	66
3.18.9	Open SPP Server.....	66
3.18.10	Query whether the peer Bluetooth is enabled with SPP Server.....	66
3.18.11	Initiate SPP connection.....	67
3.18.12	Cut SPP connection.....	67
3.18.13	Non-active connect SPP.....	67
3.18.14	Non-active cut SPP connections.....	67
3.18.15	Query the status of the local SPP server.....	68
3.18.16	Query SPP connection status.....	68
3.18.17	SPP send data.....	68
3.18.18	SPP receive data.....	68
3.18.19	Query local Bluetooth name and MAC address.....	69
3.18.20	Set local Bluetooth name.....	69

3.18.21	Set PIN code.....	69
3.18.22	Read PIN code.....	70
3.18.23	Set BR/EDR inquiry scan and page scan.....	70
3.18.24	Query BR/EDR inquiry scan and page scan settings.....	70
3.18.25	GATT registration.....	70
3.18.26	Create database.....	71
3.18.27	Create 16-bit UUID service.....	71
3.18.28	Create 128-bit UUID service.....	71
3.18.29	Create 16-bit characteristics.....	71
3.18.30	Create 128-bit characteristics.....	72
3.18.31	Create a descriptor.....	72
3.18.32	Add the created service to the database.....	72
3.18.33	Send notification.....	73
3.18.34	Send indication.....	73
3.18.35	Return host reads data from local request.....	73
3.18.36	Return the host to write data requests from the local.....	74
3.18.37	Callback.....	74
3.19	ETH.....	75
3.19.1	Network card mode settings.....	75
3.19.2	Network card mode selection.....	76
3.19.3	Driver install.....	76
3.19.4	Driver uninstall.....	77
3.19.5	Read preset MAC address from NV.....	77
3.19.6	Set MAC address.....	77
3.19.7	Set IP.....	77
3.20	Network settings.....	78
3.21	Network access methods.....	78
3.21.1	Default route priority preset.....	79
3.22	ALSA.....	80
3.22.1	Set the volume of inner speaker.....	80
3.22.2	Get the volume fo inner speaker.....	80
3.22.3	Set the mic gain.....	80
3.22.4	Get the mic gain.....	80
3.22.5	Switch voice channel.....	81
3.22.6	Query the current voice channel.....	81
3.23	Device Control.....	81
3.23.1	Enter the recovery mode.....	81
3.23.2	adb setting.....	82
3.24	DMS.....	82
3.24.1	Initialization.....	82
3.24.2	Get imei.....	82
3.24.3	Get meid.....	83
3.24.4	Get the firmware version identification code.....	83
3.24.5	Set the UE work mode.....	83
3.24.6	Release.....	83

**4. Customer version mataince.....85**

SIMCom  
Confidential


# Abbreviation

AT	ATtention; the two-character abbreviation is used to start a command line to be sent from TE/DTE to TA/DCE
DCE	Data Communication Equipment; Data Circuit terminating Equipment
DCS	Digital Cellular Network
DTE	Data Terminal Equipment
DTMF	Dual Tone Multi-Frequency
EDGE	Enhanced Data GSM Environment
EGPRS	Enhanced General Packet Radio Service
GPIO	General-Purpose Input/Output
GPRS	General Packet Radio Service
GSM	Global System for Mobile communications
HSDPA	High Speed Downlink Packet Access
HSUPA	High Speed Uplink Packet Access
I2C	Inter-Integrated Circuit
IMEI	International Mobile station Equipment Identity
IMSI	International Mobile Subscriber Identity
ME	Mobile Equipment
MO	Mobile-Originated
MS	Mobile Station
MT	Mobile-Terminated; Mobile Termination
PCS	Personal Communication System
PIN	Personal Identification Number
PUK	Personal Unlock Key
SIM	Subscriber Identity Module
SMS	Short Message Service
SMS-SC	Short Message Service-ServiceCenter
TA	Terminal Adaptor; e.g. a data card (equal to DCE)
TE	Terminal Equipment; e.g. a computer (equal to DTE)
UE	User Equipment
UMTS	Universal Mobile Telecommunications System
USIM	Universal Subscriber Identity Module
WCDMA	Wideband Code Division Multiple Access
FTP	File Transfer Protocol
HTTP	Hyper Text Transfer Protocol
RTC	Real Time Clock
NAS	Network Access Service
WDS	Wireless Data Service
QMI	Qualcomm Messaging Interface

# 1 SIM7600 Development Platform Overview

## 1.1 System Overview

The development platform of SIM7600 module is Linux system, its frame is as follows:



The SIM7600 is based on the ARM Cotex-A7 1.3GHz CPU and runs the Linux operating system. The kernel version is 3.18.20. The file system uses the UBIFS file system. The Linux-managed ubi file system contains three logical partitions:

-ubi0:rootfs:

The rootfs logical partition is read-only and holds the Linux code.

-ubi0:usrfs:

Usrfs stores the Linux file system, which is generally used for Open Linux of user applications on this partition.

-ubi0:cache:

Cache is generally used for FOTA upgrades. If there is not enough cache space during the upgrade, the upgrade program will release some of the space for FOTA upgrade by deleting unopened files. So for security reasons, it is best not to put the user's data on the cache partition.

The three partitions of SIM7600E-H are detailed in the following table:

Filesystem	Size	Used	Available	Use%	Mounted on
------------	------	------	-----------	------	------------

ubi0:rootfs	50.2M	36.1M	14.1M	72%	/
ubi0:usrfs	10.5M	364K	10.1M	3%	/data
Ubi0:cachefs	40.8M	24K	38.6M	0%	/cache

## 1.2 Open Linux selection and function

According to the needs of the market, we have introduced several models of 4G modules that support Open Linux. Customers can choose the best cost-effective solution based on their own product definition. Specific support functions are as follows:

	SIM7600E-H
Platform	MDM9x07
Memory(bit)	2+2
Protocols	TCP/IP/IPV4/IPV6/Multi PDP/FTPS/HTTPS/DNS/COAP/MQTT
CALL	.
ECALL	.
SMS	.
TLS1.2	.
Audio Record/Play	.
TTS	.
DTMF	.
LBS	.
FOTA	.
Security	
Routing policy	4G,WIFI and Ethernet port
NDIS/RNDIS	.
Bluetooth	BLE4.2 (External w58 module)
WIFI	2.4G (External w58 module)
GNSS	GPS/GLONASS/BEIDOU
SGMII	HSCI turn to LAN9730(100M)
UART	2* High UARTs
USB2.0	.
OTG	.
HSIC	.
Audio PCM	1*PCM
Audio Analog	1input+1output (Common access with PCM)
GPIO	At least 5*GPIO

SDIO	SDIO3.0 (200MHz Max)
SD Card	SD3.0 (128G Max)
SPI	Optional
I2C	1*I2C

### 1.3 Open Linux related PIN definition

SIM7600E-H

PIN No	PINNAME	SYS GPIO No.	Default Function	Function 1	Function2	Pull	Wakeup Interrupt
6	SPI_CLK	--	UART1_RTS	--	--	B-P D	
7	SPI_MISO	--	UART1_RX	--	--	B-P D	
8	SPI_MOSI	--	UART1_TX	--	--	B-P D	
9	SPI_CS	--	UART1_CTS	--	--	B-P D	
21	SD_CMD	--	SD Card	--	--	B-P D	
22	SD_DATA0	--	SD Card	--	--	B-P D	
23	SD_DATA1	--	SD Card	--	--	B-P D	
24	SD_DATA2	--	SD Card	--	--	B-P D	
25	SD_DATA3	--	SD Card	--	--	B-P D	
26	SD_CLK	--	SD Card	--	--	B-N P	
27	SDIO_DATA 1	--	WLAN	--	--	B-P D	
28	SDIO_DATA 2	--	WLAN	--	--	B-P D	
29	SDIO_CMD	--	WLAN	--	--	B-P D	
30	SDIO_DATA 0	--	WLAN	--	--	B-P D	

31	SDIO_DATA 3	--	WLAN	--	--	B-P D	
32	SDIO_CLK	--	WLAN	--	--	B-N P	
33	GPIO3	GPIO_102 0	MIFI_POWER_E N	GPIO	MIFI_POWER_E N	B-P U	
34	GPIO6	GPIO_102 3	MIFI_SLEEP_CL K	GPIO	MIFI_SLEEP_CL K	B-P D	
46	ADC2		ADC			--	
47	ADC1		ADC			B-P U	
48	SD_DET	GPIO_26	GPIO	GPIO	SD_DET	B-P D	
49	STATUS	GPIO_52	Status	GPIO	Status	B-P D	
50	GPIO43	GPIO_36	MIFI_COEX	GPIO	MIFI_COEX	B-P D	
52	GPIO41	GPIO_79	BT	GPIO	BT	B-P D	*
55	SCL	--	I2C_SCL	--	--	B-P D	
56	SDA	--	I2C_SDA	--	--	B-P U	
66	RTS	--	UART2_RTS	--	--	B-P D	
67	CTS	--	UART2_CTS	--	--	B-P D	
68	RXD	--	UART2_RX	--	--	B-P D	
69	RI	--	GPIO(RI)	--	--	B-P D	
70	DCD	--	GPIO	--	--	B-P D	
71	TXD	--	UART2_TX	--	--	B-P D	
72	DTR	--	GPIO(DTR)	--	--	B-P D	*
73	PCM_OUT	--	PCM	--	--	B-P D	
74	PCM_IN	--	PCM	--	--	B-P D	
75	PCM_SYNC	--	PCM	--	--	B-P D	
76	PCM_CLK	--	PCM	--	--	B-P	

87	GPIO77	GPIO_77	BT	GPIO	BT	U B-P D	
----	--------	---------	----	------	----	---------------	--

SIMCom  
Confidential

## 2. The environment of Open Linux

Open Linux has both Windows and Linux environments. Customers can choose their own familiar environment for development. If you only develop one application using Windows will be faster. If you are concerned with Kernel changes, it is must use the Linux environment.

### 2.1 Install Windows Embedded Compiler


#### 2.1.1 Install ARM GNU/LINUX



The development of SIM7600 is actually the development of embedded Linux. You can choose to build an ARM-Linux compiler compatible with SIM7600 platform for compiling applications under the Windows operating system.


Tools for installing applications for compiling SIM7600 under Windows system is Sourcery CodeBench for ARM GNU/Linux

Download link : [https://sourcery.mentor.com/public/gnu\\_toolchain/](https://sourcery.mentor.com/public/gnu_toolchain/)

Installation method:








## 2.1.2 Install Cygwin

In order to simplify the compilation of the application and facilitate the management of the application's code engineering, it is recommended to compile the program using make. Cygwin's make program can be used under Windows environment. Customers can download the free Cygwin from cygwin's official website.

After the installation, then add the Cygwin/bin/ path to the environment variable. As shown in the following figure:



## 2.2 Configure the Linux compilation environment

It is recommended to use Ubuntu12.04 64-bit as a compiler system.

### 2.2.1 Compilation method

Using sudo tar command to extract sdk archive, such as extracting to the current directory command as follow:

```
sudo tar xzf sim_open_sdk.tar.gz
```

Then initialize the environment variable in the sim\_open\_sdk directory, the command is as follows:

```
source sim_crosscompile/sim-crosscompile-env-init
```

#### 2.2.1.1 Compile all

Executing make command in the sim\_open\_sdk directory. All the images generated after the compilation is completed are in the sim\_open\_sdk/output directory, as follows.

```
appsboot.mbn boot.img system.img
```

### 2.2.1.2 Compile bootloader

Executing 'make about' in the sim\_open\_sdk directory.  
The image is in the sim\_open\_sdk/output directory as follows.

```
appsboot.mbn
```

### 2.2.1.3 Compile kernel

- 1) Executing make kernel\_menuconfig in sim\_open\_sdk directory to configure the kernel, and then pop up the graphical configuration interface. If you need to add new configuration options select the corresponding configuration in the graphical configuration interface, then save and exit. If you do not add new configuration just quit. After the configuration is complete, the .config file will be generated in the sim\_kernel/build/ directory.
- 2) Executing make kernel to compile the kernel. The generated kernel image is in the sim\_open\_sdk/output directory.

```
boot.img
```

### 2.2.1.4 Generate rootfs file system image

Executing make rootfs in the sim\_open\_sdk directory and the generated image is in the sim\_open\_sdk/output directory.

```
system.img
```

### 2.2.1.5 Compile driver module

Executing make kernel\_module to compile the driver module. After the compilation is successful, it will be automatically installed in the corresponding directory of sim\_rootfs, so then execute make rootfs to regenerate the rootfs file system image.

### 2.2.1.6 Compile demo

Executing `make demo` to compile the demo program and the generated image is in the `sim_open_sdk/output` directory.

`demo_app`

### 2.2.1.7 Clear the generated image

- 1) Clear all and execute `make clean`.
- 2) Clear bootloader and execute `make about_clean`.
- 3) Clear kernel and execute `make kernel_clean`.
- 4) Clear rootfs and execute `make rootfs_clean`.
- 5) Clear demo and execute `make demo_clean`.

### 2.2.1.8 Question

1) If you execute `make kernel_menuconfig` to configure the kernel, the following error occurs.  
error: `../scripts/kconfig/lxdialog/dialog.h: fatal error: curses.h: No such file or directory`  
Executing `sudo apt-get install libncurses5-dev`.

## 2.2.2 Making OTA upgrade package command

It needs to provide both the current version package source and the target version package target to make ota upgrade package. Both source and target need to be placed under the `sim_open_sdk/sim_ota` directory.

### 1) generation of target

When the application is ready, the bootloader, kernel and system are all compiled. That is after `appsboot.mbn`, `boot.img` and `system.img` have been generated in the output directory, `make ota` command will be executed in the `sim_open_sdk` directory, and then the prepared target can be seen in the `sim_open_sdk/sim_ota` directory.


- 2) The source prepared by the customer is put into the `sim_open_sdk/sim_ota` directory, and the source structure is the same as the target structure.
- 3) Executing `ota.sh` under the `sim_open_sdk` directory will generate the ota upgrade package, which is under the `sim_open_sdk/output` directory, as follows:

update\_ota2+1.zip update\_ota.zip

The differential modes of two packages are different. When update please use update\_ota2+1.zip.

## 2.3 Install Windows driver

After connecting the SIM7600's USB to the computer, some USB virtual devices will appear and drivers will need to be installed. Please use the corresponding Windows driver installation package to install. After installation will as shown below:



Each device corresponds to the function as shown below:

Interface number	windows name	Linux name	Interface description
0	SimTech HS-USB Diagnostics	USB serial	Diagnostic Interface
1	SimTech HS-USB NMEA	USB serial	GPS NMEA Interface
2	SimTech HS-USB AT Port	USB serial	AT port Interface
3	SimTech HS-USB Modem	USB serial	Modem port Interface
4	SimTech HS-USB Audio	USB serial	USB Audio Interface
5	SimTech HS-USB WWAN Adapter	USB Net	NDIS wwan interface
6	Android Composite ADB Interface	USB adb	Android add debug port


The adb device of SIM7600 is closed by default. It needs to be opened by AT command setting, and then restart the module to take effect. The command is AT+CUSBADB=1

After the command returns OK, you need to restart the module manually. You can see an Android


Composite ADB Interface device from the Windows device manager, which indicates that the adb device can be used.

Note:

If the computer is installed with the ADB device for the first time, then add the adb\_usb.ini file in the '.android' directory under the current login account in the 'user' on the C drive, and add the VID of the SIM7600 to 0x1E0E in the file.




Adb tool can be tested in the Windows cmd window.



adb shell can access the SIM7600 Linux system console.

Use alias ls='ls-color=null' to align the system's display, as shown below:



## 2.4 Debug download tool

NOTE:

Module software version must be open linux development version can only be in accordance with the instructions below to use fastboot to download each partitions. If not the open linux development version, it

needs to upgrade to an open linux development version before the operation. Through the at command ati, you can check whether it is open linux development version or not. If the version information contains keywords OL, it is an open linux development version.

You must use the tool to download a full open linux development version when download version for the first time. It may cause some function can't be normal used if update part version files using fastboot.

Regardless of the application or compiled image file, it is recommended to use windows to download and debug.

Application debugging uses the adb tool and image download uses the fastboot tool. These two tools can be downloaded from the Internet or use the environment compression package provided by us.

The adb tool can push the app program into the module. The app runs in the foreground and can print all app's log. Same as standard linuxdmesg can print all the kernel's logs.

```
c:\>adb push helloworld /data/helloworld
629 KB/s (5800 bytes in 0.009s)

c:\>adb shell
/ # chmod a+x /data/helloworld
chmod a+x /data/helloworld
/ # ./data/helloworld
./data/helloworld
```

Fastboot tool can download appsboot.mbn, modem.img, boot.img, system.img, recovery.img and recoveryfs.img.

Use AT command at+bootldr or adb command adb reboot bootloader to enter fastboot mode, you can download the above image.

```
E:\>adb reboot bootloader

E:\>fastboot flash aboot E:\7600\LE11B01U01SIM7600L\appsboot.mbn
target reported max download size of 134217728 bytes
sending 'aboot' (384 KB)...
OKAY [ 0.017s]
writing 'aboot'...
OKAY [ 0.728s]
finished. total time: 0.748s

E:\>fastboot flash boot E:\7600\LE11B01U01SIM7600L\boot.img
target reported max download size of 134217728 bytes
sending 'boot' (5412 KB)...
OKAY [ 0.178s]
writing 'boot'...
OKAY [ 1.604s]
finished. total time: 1.867s

E:\>fastboot flash system E:\7600\LE11B01U01SIM7600L\system.img
target reported max download size of 134217728 bytes
sending 'system' (43008 KB)...
OKAY [ 1.362s]
writing 'system'...
OKAY [ 20.118s]
finished. total time: 21.485s

E:\>fastboot flash modem E:\7600\LE11B01U01SIM7600L\modem.img
target reported max download size of 134217728 bytes
sending 'modem' (37632 KB)...
OKAY [ 1.192s]
writing 'modem'...
OKAY [ 11.740s]
finished. total time: 12.936s


E:\>fastboot flash recovery E:\7600\LE11B01U01SIM7600L\recovery.img
target reported max download size of 134217728 bytes
sending 'recovery' (6006 KB)...
OKAY [ 0.195s]
writing 'recovery'...
OKAY [ 1.857s]
finished. total time: 2.056s

E:\>fastboot flash recoveryfs E:\7600\LE11B01U01SIM7600L\recoveryfs.img
target reported max download size of 134217728 bytes
sending 'recoveryfs' (8576 KB)...
OKAY [ 0.280s]
writing 'recoveryfs'...
OKAY [ 2.643s]
finished. total time: 2.928s
```

## 2.5 Application Compilation and Run

### 2.5.1 Demo application

Demo's directory structure



Note: All 'demo' mentioned in this article are in the SDK. The directory is simcom-demo.

### 1) Demo program compiled under windows

Copy the Makefile\_win file in the tools directory to the simcom-demo directory and rename it to Makefile. Next compile directly with make command and generate demo\_app application in the simcom-demo/bin directory. The compiled executable file is imported into the data directory of the SIM7600 Linux system by adb push, and the execute permission is added. Then the adb shell can be used to enter the SIM7600 Linux console to manually debug the execution program. During the debugging phase, the client starts and debugs the application through the control terminal of the adb shell. The code can use the printf method to debug the log and information.

## 2) Demo program compiled under linux

See section 2.2.1.6 for the compilation method.

### 2.5.2 Helloworld application

#### 1) Compile helloworld

Executing make helloworld, and the generated application is in the sim\_open\_sdk/output directory.

#### 2) Helloworld Self-starting settings

Copy the application helloworld compiled above to the sim\_open\_sdk/sim\_usrfs directory. Then copy the sim\_open\_sdk/helloworld/start\_helloworld file to the sim\_open\_sdk/sim\_rootfs/etc/init.d/ directory and executes the following command in the sim\_open\_sdk directory.

```
sudo ln -sf ../init.d/start_simcom_demo sim_rootfs/etc/rc5.d/S99start_simcom_demo
```

Then regenerate the rootfs image according to Section 2.2.1.4.

## 2.6 System partition and file protection

In system partition, system, data and cache are divided into one physical partition. The size of the three logical partitions can be dynamically adjusted. The adjusted file is sim\_open\_sdk/tools/ubinize\_system\_userdata.cfg

```
[sysfs_volume]
mode=ubi
image=./mdm9607-perf-sysfs.ubifs
vol_id=0
vol_type=dynamic
vol_name=rootfs
vol_size=55MiB // Adjust the size of the system partition here
[usrfs_volume]
mode=ubi
image=./usrfs/mdm9607-perf-usrfs.ubifs
vol_id=1
vol_type=dynamic
vol_name=usrfs
vol_flags = autoresize//Data partition size is set automatically
[cache_volume]
mode=ubi
vol_id=2
vol_type=dynamic
vol_name=cachefs
vol_size=45MiB //Adjust the size of the cache partition here
```

All necessary files in the system must be placed in the system directory. The temporarily generated files are placed in the data directory. Note that system is a read-only directory. The data files stored as temporary files may be lost under certain extreme conditions.

When the system is running, in order to ensure the security of the process the scheme of /data and /cache

backup is adopted. (Refer to helloworld/helloworld.c and helloworld/helloworld\_auto\_restore.sh in the open linux environment.)

Application under module /data: /data/helloworld

The version identifier of the application under module /data: /data/helloworld\_ver.txt

Application under module /cache: /cache/helloworld\_bak

The version identifier of the application under module/cache: /cache/helloworld\_bak\_ver.txt

(1) Execute the detection script /etc/init.d/helloworld\_auto\_restore.sh when the module is powered on.

(2) The first boot will copy /data/helloworld to /cache/helloworld\_bak and execute /data/helloworld

(3) If /data/helloworld does not exist, copy /cache/helloworld\_bak to /data/helloworld.

if /cache/helloworld\_bak does not exist, copy /data/helloworld to /cache/helloworld\_bak.

(4) If both exist, the version identifier corresponding to the two is determined. If the two are inconsistent, the higher version of the program is overwritten to the lower version of the program.

(5) Application upgrade strategy

1) /data/helloworld deletes /cache/helloworld\_bak\_ver.txt and /cache/helloworld\_bak in order.

2) /data/helloworld downloads the target program to /cache/helloworld\_bak.

3) /data/helloworld starts /cache/helloworld\_bak update &

4) /cache/helloworld\_bak writes its own version ID.

5) Reboot


Note:

Due to the caching principle of the Linux system, the file operation will not be immediately written to the flash, and abnormal power failure will result in file corruption or loss. Therefore, for important file operations, you need to execute the sync command to ensure the operation is complete.

## 2.7 Production line production mode

### 2.7.1 Download APP separately

SIMCom provides a tool for the production line to download customer developed applications. As shown below:



The basic principle of this tool is that the customer selects his own compiled application file and then selects Down File. The tool will place this program in the module /data and /usr/bin directory and rename it 'helloworld', and then automatically modify it to executable permissions. The next time the module is booted, it will automatically check if there is helloworld under data. If so, it will automatically execute and complete the client's program startup.

## 2.7.2 Download the compiled image

Providing production line tools for customers to download and use directly. You can download them in four places at the same time. After the tools are installed there will be instructions for use.



## 3. Programming Guide

### 3.1 System basic API

The basic API of the SIM7600 Linux system is the same as all Linux systems. But timer and RTC timer are different. The RTC timer is still accurate after the system sleeps. TCP (socket) demo with the use of Linux can refer to the specific code DEMO.

### 3.2 Embedded AT transceiver

The Open Linux application can use the functions of all AT commands. AT command communication is supported by using the tty device node `/dev/smd8` in Linux.

#### 3.2.1 Send AT command interface

<b>Interface</b>	<code>int sendATCmd(char* atCmd, char* finalRsp, char *buff, uint32_t buffSize, long timeout_ms)</code>
<b>Input</b>	<p><code>atCmd</code>: AT command</p> <p><code>finalRsp</code>: Expected return value with string</p> <p><code>buff</code>: <b>AT</b> returns value all content pointer</p> <p><code>buffSize</code>: AT returns value All content pointer size, at least 100 bytes</p> <p><code>timeout_ms</code>: AT timeout</p>
<b>Output</b>	None
<b>Return vaule</b>	0: success    -1: failureOther: AT returns content length
<b>NOTE</b>	

### 3.3 UART

**SIM7600E-H**: Dual high-speed serial interface UART1 and UART2. Device nodes are UART1: `/dev/ttyHS0` (It can be configured as Bluetooth) and UART2: `/dev/ttyHS1`. All serial ports do not support the use of AT commands.

The specific parameters are as follows:

Parameters	Value ranges	Defaults	Setting method
Start bit	1bit	1bit	ioctl
Data bit	7bit,8bit	8bit	
Stop bit	1bit,2bit	1bit	
Check digit	Odd,Even,Space, None	None	
Baud rate	300,600,1200,2400,4800,9600,19200,38400,57600,115200,230400,460800,921600,1000000,1152000,1500000,3000000,3200000,3686400	115200	ioctl
Single frame send size	512B	512B	
Single frame response delay	( 1-10 ) ms ( The time that Host needs to wait after each single frame is sent synchronously )	1ms(recommend)	
Maximum buffer	10KB	10KB	

**SIM7600E-H** Its PIN definition is as follows:

PIN No	PINNAME	Default Function	Pull	Wakeup Interrupt
6	SPI_CLK	UART1_RTS	B-PD	
7	SPI_MISO	UART1_RX	B-PD	
8	SPI_MOSI	UART1_TX	B-PD	
9	SPI_CS	UART1_CTS	B-PD	
66	RTS	UART2_RTS	B-PD	
67	CTS	UART2_CTS	B-PD	
68	RXD	UART2_RX	B-PD	
71	TXD	UART2_TX	B-PD	

### 3.4 GPIO

The following is a description of the SIM7600E-T GPIO controllable PIN:

PI N No	PINNAME	SYS GPIO No.	Default Function	Function 0	Function 1	Pull	Wakeup Interrupt
33	GPIO3	GPIO_1020	MIFI_POWER_EN	GPIO	MIFI_POWER_EN	B-P U	
34	GPIO6	GPIO_102	MIFI_SLEEP_CL	GPIO	MIFI_SLEEP_CL	B-P	

		3	K		K	D	
48	SD_DET	GPIO_26	GPIO	GPIO	SD_DET	B-P D	*
49	STATUS	GPIO_52	Status	GPIO	Status	B-P D	*
50	GPIO43	GPIO_36	MIFI_COEX	GPIO	MIFI_COEX	B-P D	
51	NETLIGHT	GPIO_18	NETLIGHT	GPIO	NETLIGHT	B-P D	
52	GPIO41	GPIO_79	BT_PCM	GPIO	BT_PCM	B-P D	*
54	FLIGHTMODE	GPIO_76	BT_PCM	GPIO	BT_PCM	B-P D	*
69	UART_RI	GPIO_50	GPIO(RI)	GPIO	GPIO	B-P D	
70	UART_DCD	GPIO_51	GPIO	GPIO	GPIO	B-P D	
72	UART_DTR	GPIO_74	GPIO(DTR)	GPIO	GPIO	B-P D	*
86	COEX3	GPIO_78	BT_PCM	GPIO	BT_PCM	B-P D	
87	GPIO77	GPIO_77	BT_PCM	GPIO	BT_PCM	B-P D	

Note:

- If it doesn't need the BT\_PCM function, you can export the corresponding SYS GPIO No to using as GPIO.
- If the UART is configured to low speed serial ports, the CTS and RTS can be using as GPIO.
- The following is a description of the SIM7600E-H GPIO controllable PIN:
- The following is a description of the SIM7600E-H GPIO controllable PIN:

The following is a description of the SIM7600E-H GPIO controllable PIN:

PI N No	PINNAME	SYS GPIO No.	Default Function	Function 0	Function 1	Pull	Wakeup Interrupt
33	GPIO3	GPIO_102 0	MIFI_POWER_E N	GPIO	MIFI_POWER_E N	B-P U	
34	GPIO6	GPIO_102 3	MIFI_SLEEP_CL K	GPIO	MIFI_SLEEP_CL K	B-P D	
48	SD_DET	GPIO_26	GPIO	GPIO	SD_DET	B-P D	*
49	STATUS	GPIO_52	Status	GPIO	Status	B-P D	*
52	GPIO41	GPIO_79	BT	GPIO	BT	B-P	*

						D	
50	GPIO43	GPIO_36	MIFI_COEX	GPIO	MIFI_COEX	B-P D	
69	UART_RI	GPIO_50	GPIO(RI)	GPIO	GPIO	B-P D	
70	UART_DC D	GPIO_51	GPIO	GPIO	GPIO	B-P D	
72	UART_DTR	GPIO_74	GPIO(DTR)	GPIO	GPIO	B-P D	*
87	GPIO77	GPIO_77	BT	GPIO	BT	B-P D	

Note:

- PIN50, PIN52, and PIN87 boot phases are used as BOOT\_CFG. So if you want to use these GPIOs for development, they only serve as outputs.
- PIN69 is fixed as the PIN pin for waking up the MCU and PIN72 is fixed as the PIN pin for the MCU wake-up module.

Instance:

1) GPIOConfiguration

About GPIO operation method:

Via the `/sys/class/gpio/***` file node. This method requires attention to the correspondence between PIN No. and SYS GPIO No.

1)). Dynamically establish GPIO file node and write GPIO number to `/sys/class/gpio/export` file. For example using PIN50:

```
echo 36 > /sys/class/gpio/export
```

2)). Pull up or pull down GPIO and set GPIO as output first, then set output high and low.

For example pull up PIN50:

```
echo 36 > /sys/class/gpio/export
```

```
echo out > /sys/class/gpio/gpio36/direction
```

```
echo 1 > /sys/class/gpio/gpio36/value
```

3)). Read GPIO-first set GPIO as input and then read the status.

```
echo in > /sys/class/gpio/gpio36/direction
```

```
cat /sys/class/gpio/gpio36/value
```

2) GPIO Interrupt configuration

Methods:

```
echo "in" > /sys/class/gpio/gpio36/direction
```

```
echo "both" > /sys/class/gpio/gpio36/edge
```

The state of the poll value node is required to trigger the response in real time.

### 3.5 ADC

The module provides two ADC analog-to-digital conversion interfaces corresponding to the module PIN46.PIN47. They correspond to ADC2 and ADC1, respectively. The developer can read the corresponding device file to obtain the voltage value.

<b>Interface</b>	int read_adc(int ch)
<b>Input</b>	ch :aisle
<b>Output</b>	None
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.6 I2C

**SIM7600E-H:** SDA and SCL correspond to the PIN55 and PIN56 of the module, respectively. The developer first opens the /dev/i2c-5 devices to obtain the handle, and then calls the read-write function to operate the device.

#### 3.6.1 Write I2C interface

<b>Interface</b>	int sim_i2c_write(uint8_t slave_address, uint16_t reg, uint8_t *buf, int len)
<b>Input</b>	slave_address    Device slave address reg                Device register buf                Data bufferto be written len                Data length
<b>Output</b>	None
<b>Return value</b>	0: success    -1: failure    Other: data length
<b>Interface</b>	int sim_i2c_write(uint8_t slave_address, uint16_t reg, uint8_t *buf, int len)

#### 3.6.2 Read I2C interface

<b>Interface</b>	int sim_i2c_read(uint8_t slave_address, uint16_t reg, uint8_t *buf, int len)
<b>Input</b>	slave_address    Device slave address

	reg	Device register
	len	Data length
<b>Output</b>	buf	Data bufferto be read
<b>Return value</b>	0: success	-1: failure
<b>NOTE</b>		

## 3.7 SD Card/EMMC flash

Through the SDIO PIN (21-26), external SD Card or EMMC, the default mount / etc / card shortcut is / sdcard. Partitioning and formatting need to be done once on the production line and using the AT command AT + CFDISK. After the system default mount only the first partition is / sdcard, other partitions need to use the command to do mount in the APP.

### 3.7.1 Partition

Using AT command 'AT+CFDISK=<num>[,<size>]' to finish partition.

### 3.7.2 Format

After the first partition, use the AT command 'AT+CFDISK' to format.

### 3.7.3 Mount

The module will automatically mount /dev/mmcbk0p1 to /media/card. For other partitions, users need to mount.

For example mounting /dev/mmcbk0p2 to /mnt:

```
mount-t auto /dev/mmcbk0p2 /mnt
```

### 3.7.4 CFDISK Command

## AT+CFDISK

<p>Test Command <b>AT+ CFDISK=?</b></p>	<p>Response a)If successfully: <b>+CFDISK: (1-4)[...]</b> <b>OK</b> b)If failed: <b>ERROR</b></p>
<p>Read Command <b>AT+ CFDISK?</b></p>	<p>Response a)If successfully: <b>+CFDISK: &lt;num&gt;,&lt;size&gt;</b> <b>OK</b> b)If failed: <b>ERROR</b></p>
<p>Write Command <b>AT+ CFDISK=&lt;num&gt;[,&lt;size&gt;,...]</b></p>	<p>Response a)If successfully: <b>OK</b> b)If failed: <b>ERROR</b></p>
<p>Write Command(Formatting all partitions) <b>AT+ CFDISK</b></p>	<p>Response a)If successfully: <b>OK</b> b)If failed: <b>ERROR</b></p>

#### Defined values

<b>&lt;num&gt;</b>	Partition number
<b>&lt;size&gt;</b>	Partition size.The unit is KB. NOTE:The last partition size does not need to be set. The size of the last partition is the size of the disk remaining.

#### Examples

```

AT+CFDISK=?
OK+CFDISK: (1-4)[...]

OK
AT+CFDISK=4,50000,50000,50000
OK
AT+CFDISK
OK
AT+CFDISK?
+CFDISK: 1,50040
+CFDISK: 2,50048
+CFDISK: 3,50048
+CFDISK: 4,3708288

OK

```

## 3.8 UIM

Customers can use UIM's related functions to obtain some information about the SIM card, such as ICCID and IMSI.

### 3.8.1 Check SIM card status

<b>Interface</b>	int getSimCardStatus(SimCard_Status_type *simStatus);
<b>Input</b>	None
<b>Output</b>	<p>simStatus</p> <p>card_status: 0: No SIM card detected 1: SIM card detected2: Unknown mistake</p> <p>app_type: types ofSIM card1: SIM 2: USIM 3: RUIM 4: CSIM 5: ISIM</p> <p>app_state:1: detected 2: pin block 3: puk block 4: person check 5:Permanently blocked 6: illegal</p> <p>pin_state:1: unknown 2: Enabled and not verified 3: Enabled and verified 4: Disabled 5: Blocked 6:Permanently blocked)</p> <p>pin_retries:The number of remaining solutions pin</p> <p>puk_retries:The number of remaining solutions puk</p>
<b>Return value</b>	0: success -1: failure
<b>NOTE</b>	

### 3.8.2 Query SIM card ICCID

<b>Interface</b>	int get_iccid(char *piccid);
<b>Input</b>	None
<b>Output</b>	piccid: ICCID
<b>Return value</b>	0: success -1: failure
<b>NOTE</b>	piccid is a pointer or an array of at least 21 bytes in length and the content has been initialized to 0.

### 3.8.3 Query SIM card IMSI

<b>Interface</b>	int get_imsi(char *imsi);
<b>Input</b>	None
<b>Output</b>	imsi: IMSI
<b>Return value</b>	0: success -1: failure
<b>NOTE</b>	Imsi is a pointer or an array of at least 16 bytes in length, and the content has been initialized to 0.

## 3.9 SMS

Send and receive SMS.

### 3.9.1 SMS initialization

<b>Interface</b>	int sms_init(sms_ind_cb_fcn sms_ind_cb);
<b>Input</b>	sms_ind_cb: For receiving SMS messages
<b>Output</b>	None
<b>Return value</b>	0: success -1: failure
<b>NOTE</b>	After initialization to perform another SMS operation.

### 3.9.2 Set receive SMS format

<b>Interface</b>	void sms_set_format(sms_format format);
<b>Input</b>	format: 1:ASCII not use 2:UTF8 default 3:UCS2
<b>Output</b>	None
<b>Return value</b>	None
<b>NOTE</b>	The format is ASCII for English SMS, the default format is UTF8 for Chinese SMS, you can call this API to switch the format to UCS2.

### 3.9.3 Send messages

<b>Interface</b>	int send_message(int smsMode, char *phoneNumber, unsigned char *content, int content_len);
<b>Input</b>	<p>smsMode: 1:ASCII 2:UTF8 3:UCS2</p> <p>phoneNumber: Destination of phone number</p> <p>content: message content</p> <p>content_len: length of content</p>
<b>Output</b>	None
<b>Return value</b>	0: success -1: failure
<b>NOTE</b>	

### 3.9.4 Callback function handles message reception

<b>Interface</b>	void process_simcom_ind_message(simcom_event_e event, void *cb_usr_data);
<b>Input</b>	None
<b>Output</b>	<p>event=SIMCOM_EVENT_SMS_PP_IND</p> <p>cb_usr_data: Corresponding structure</p> <pre>typedef struct {     boolean    is_concat;     uint8      msg_ref;     uint8      seq_num;     uint8      total_sm;     sms_format format;     int        message_len;     char        message_content[SMS_MAX_CONTENT_LENGTH];     char        source_address[SMS_MAX_ADDRESS_LENGTH]; } sms_info_type;</pre> <p>is_concat: long message flag, 1 indicates long message</p> <p>msg_ref: message ID for long message, the same message ID indicates the same one message.</p> <p>seq_num: the message index in the whole long message</p> <p>total_num: the total message number for a whole long message</p> <p>format: 1:ASCII 2:UTF8 3:UCS2</p> <p>message_len: message length</p> <p>message_content: message content</p> <p>source_address: phone number</p>
<b>Return value</b>	None
<b>NOTE</b>	This function is passed in Init as a parameter.

## 3.10 Voice Call

Make and receive voice calls while monitoring the status of voice calls.

### 3.10.1 Phone initialization

<b>Interface</b>	int Init();
<b>Input</b>	None
<b>Output</b>	None
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	After initialization to perform other operations on the phone.

### 3.10.2 Dial number

<b>Interface</b>	int voice_dial(char *phoneNum);
<b>Input</b>	Phone Num: The number you need to dial
<b>Output</b>	None
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.10.3 Handle current call

<b>Interface</b>	int voice_mtcalls_process(voice_call_option option, unsigned char call_id);
<b>Input</b>	Option: 1: Hang up the phone, only one call for the current 2: Answer, only one call for the current 3: Keep the call, keep the current call and pick up the new call 4: Hang up all calls 5: Hang up hold call 6: Hang up current call Call_id:optionEquivalent to 1 or 2
<b>Output</b>	None
<b>Return value</b>	0: success    -1: failure

**NOTE**

### 3.10.4 Get the status of the specified call

<b>Interface</b>	int get_call_info(uint8_t callid, call_info2_type *pcall_info);
<b>Input</b>	callid Non-zero value
<b>Output</b>	pcall_infoStructure contains parameters: 1 call_id, - same as input 2 call_state: 1: Start a call 2: Incoming call 3: Call establishment 5: Bell 6: Call holding 7: Call waiting 8: Hanging 9: Hang up 3 Direction: 1: Exhale 2: Call in 4 Number
<b>Return value</b>	0: success -1: failure
<b>NOTE</b>	

### 3.10.5 Get all call states

<b>Interface</b>	int get_all_call_info(call_info_type *pcall_info_list);
<b>Input</b>	
<b>Output</b>	pcall_info_list Structure contains parameters: 1. call_num - There are currently several calls 2. call_info: 2.1 call_id, - Same as input 2.2 call_state: 1: Start a call 2: Incoming call 3: Call establishment 5: Bell 6: Call holding 7: Call waiting

	8: Hanging 9: Hang up 2.3 Direction: 1: Exhale 2: Call in 2.4 Number
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.10.6 Callback

<b>Interface</b>	void      process_simcom_ind_message(simcom_event_e      event,void *cb_usr_data)
<b>Input</b>	
<b>Output</b>	Event = SIMCOM_EVENT_VOICE_CALL_IND cb_usr_dataStructure contains parameters: 1. call_num    - There are currently several calls 2. call_info: 2.1 call_id,    - Same as input 2.2 call_state: 1: Start a call 2: Incoming call 3: Call establishment 5: Bell 6: Call holding 7: Call waiting 8: Hanging 9: Hang up 2.3 Direction: 1: Exhale 2: Call in 2.4 Number
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.11 NAS

NAS interface is mainly used to obtain some information about the status of the network, such as

registering network types and signals.

### 3.11.1 Query registration network status

<b>Interface</b>	int get_NetworkType(nas_serving_system_type_v01 *serving_system);
<b>Input</b>	None
<b>Output</b>	<p>serving_system</p> <p>registration_state:</p> <ul style="list-style-type: none"> <li>- 0x00 –unregistered</li> <li>- 0x01 –registered</li> <li>- 0x02 –Search network</li> <li>- 0x03 –Registration refused</li> <li>- 0x04 –Unknown state</li> </ul> <p>cs_attach_state: CS domain status, whether the attachment is successful or not</p> <ul style="list-style-type: none"> <li>- 0x00 –Unknown</li> <li>- 0x01 –Attached successfully</li> <li>- 0x02 –Attached unsuccessfully</li> </ul> <p>ps_attach_state : PS domain status, whether it is attached successfully determines whether it can dial up the Internet.</p> <ul style="list-style-type: none"> <li>- 0x00 --Unknown</li> <li>- 0x01 --Attached successfully (Note: Success does not mean that you can access the Internet, but also need to dial)</li> <li>- 0x02 --Attached unsuccessfully</li> </ul> <p>selected_network;network types</p> <ul style="list-style-type: none"> <li>- 0x00 –Unknown</li> <li>- 0x01 –3GPP2</li> <li>- 0x02 –3GPP</li> </ul> <p>radio_if_len: Number of registered networks (The effective number is one. However, there may be two for telecom cards and they may register on LTE and CDMA at the same time.)</p> <p>radio_if[];Registered network array</p> <ul style="list-style-type: none"> <li>-0x00 –No service</li> <li>-0x01 –CDMA_1X</li> <li>-0x02 –CDMA_EVDO</li> <li>-0x04 -- GSM</li> <li>-0x05 -- UMTS</li> <li>-0x08 -- LTE</li> </ul>
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.11.2 Query signal

<b>Interface</b>	int get_SignalStrength(int * signalStrength);
<b>Input</b>	None
<b>Output</b>	signalStrength: Signal value
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.12 WDS

Wds interface is mainly used to query and set APN

#### 3.12.1 Query APN

<b>Interface</b>	int get_apnInfo(int profile_index, int* pdp_type, char* apn_str, char *username, char *password);
<b>Input</b>	None
<b>Output</b>	profile_index: APN index pdp_type: pdp types - 0 -- IPv4 - 2 -- IPv6 - 3 -- IPv4 and IPv6 apn_str: APN string username: password:
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

#### 3.12.2 Set APN

<b>Interface</b>	int set_apnInfo(int profile_index, int pdp_type, char* apn_str, char *username, char *password);
<b>Input</b>	profile_index: (1~16) : APN index to be queried

	<p>pdp_type: pdp types, General choice 0</p> <ul style="list-style-type: none"> <li>- 0 -- IPv4</li> <li>- 2 -- IPv6</li> <li>- 3 -- IPv4 and IPv6</li> </ul> <p>apn_str: APN string</p> <p>username: If not, set to NULL</p> <p>password: If not, set to NULL</p>
<b>Output</b>	None
<b>Return value</b>	0: success -1: failure
<b>NOTE</b>	

### 3.13 Data Call

It is used to complete setting/inquiry for APN, dialing username and password under CDMA network. With a connection to the network, disconnect the network connection and other functions. Up to 8 links are supported at the same time. The data link used by the APP suggests starting with the 7th profile.

#### 3.13.1 Initialize the network

<b>Interface</b>	int Init();
<b>Input</b>	None
<b>Output</b>	None
<b>Return value</b>	None
<b>NOTE</b>	

#### 3.13.2 Create data link

<b>Interface</b>	int start_dataCall(int profile);
<b>Input</b>	profile: profile serial number
<b>Output</b>	None
<b>Return value</b>	0: success-1: failure
<b>NOTE</b>	

### 3.13.3 Get data link parameters

<b>Interface</b>	int get_datacall_info(int profile, datacall_info_type *pcallinfo);
<b>Input</b>	profile: profile serial number
<b>Output</b>	<pre> datacall_info_type *pcallinfo typedef struct {     dsi_hndl_t handle; //Link handle     enum app_tech_e tech; //Use standard     int family; //IP type     int profile; //profile serial     datacall_status_type status; //Current link status     char if_name[32]; //Interface name     char ip_str[16]; //IP address     char pri_dns_str[16]; //primaryDNS     char sec_dns_str[16]; //secondaryDNS     char gw_str[16]; //Gateway     unsigned int mask; //Mask }datacall_info_type; </pre>
<b>Return value</b>	0: success -1: failure
<b>NOTE</b>	

### 3.13.4 Release network resources

<b>Interface</b>	int Delnit();
<b>Input</b>	None
<b>Output</b>	None
<b>Return value</b>	None
<b>NOTE</b>	

## 3.14 GNSS

It enables the opening and closing of GNSS, the use of XTRA, and the output of NMEA and latitude and longitude.

### 3.14.1 Initialize gnss

<b>Interface</b>	static boolean gps_init();
<b>Input</b>	None
<b>Output</b>	None
<b>Return value</b>	TRUE: success    FALSE: failure
<b>NOTE</b>	This function must be executed before all other operations.

### 3.14.2 EnableXTRA

<b>Interface</b>	static void gps_xtra_enable();
<b>Input</b>	None
<b>Output</b>	None
<b>Return Value</b>	None
<b>NOTE</b>	If you need to use XTRA you must be ENABLE before turning on GNSS, and need to be connected to the module.

### 3.14.3 Prohibit XTRA

<b>Interface</b>	static void gps_xtra_disable();
<b>Input</b>	None
<b>Output</b>	None
<b>Return value</b>	None
<b>NOTE</b>	

### 3.14.4 GNSS Cold Start

<b>Interface</b>	static boolean gps_coldstart();
<b>Input</b>	None
<b>Output</b>	None
<b>Return value</b>	TRUE: success    FALSE: failure
<b>NOTE</b>	When the signal is good, the cold start is about 35 seconds

### 3.14.5 GNSS Hot Start

<b>Interface</b>	static boolean gps_hotstart();
<b>Input</b>	None
<b>Output</b>	None
<b>Return value</b>	TRUE: success    FALSE: failure
<b>NOTE</b>	

### 3.14.6 GPS Stop

<b>Interface</b>	static boolean gps_stop();
<b>Input</b>	None
<b>Output</b>	None
<b>Return value</b>	TRUE: success    FALSE: failure
<b>NOTE</b>	

### 3.14.7 Callback function output brief location information

<b>Interface</b>	void          process_simcom_ind_message(simcom_event_e          event,void *cb_usr_data)
<b>Input</b>	None
<b>Output</b>	None
<b>Return value</b>	
<b>NOTE</b>	<p>After turning on GNSS and positioning it will output latitude, longitude, time, height, speed and etc.  Event = SIMCOM_EVENT_LOC_IND  cb_usr_datastructure type:</p> <pre>typedef struct {     double          latitude;     double          longitude;     double          altitude;     float          speed;     float          bearing;     float          accuracy;     //time[0] = year-2000     //time[1] = month</pre>

```
//time[2] = day
//time[3] = time
//time[4] = minute
//time[5] = second
uint8_t time[6];
} GpsInfo;
```

### 3.14.8 Callback function output NMEA statement

<b>Interface</b>	void process_simcom_ind_message(simcom_event_e event,void *cb_usr_data)
<b>Input</b>	None
<b>Output</b>	None
<b>Return value</b>	None
<b>NOTE</b>	Turn on NMEA statements every second after opening GNSS Event = SIMCOM_EVENT_NMEA_IND cb_usr_data type char

## 3.15 WIFI

Description of function:

Recommend customers choose W58 module, which encapsulates Qualcomm QCA9377 WIFI chip.

Specifications of W58 module:

- SDIO 3.0 interface, RelatedPIN (27-32)
- 20MHz/40MHz (2.4GHz)
- As AP mode, it connects 30 nodes.
- 1X1 Single antenna design so has low cost solution.

Software function:

- Support WIFI AP/station mixed mode
- Supports communication between devices connected to WIFI hotspots and connected Module devices
- Support hidden WIFI hotspot function
- Provides AT commands for configuring WIFI and routing protocols

Special Instructions:

- get\_wifi\_mode and set\_wifi\_mode apply to W58, W58L cannot use.
- sta\_init and get\_sta\_status apply to W58L, W58 cannot use.

### 3.15.1 Get current WIFI mode settings (for W58)

<b>Interface</b>	wifi_mode_type get_wifi_mode()
<b>Input</b>	None
<b>Output</b>	None
<b>Return value</b>	wifi_mode_type: 0: Single AP mode 1: Dual AP mode 2: AP+STA mode
<b>NOTE</b>	

### 3.15.2 Set WIFI mode (for W58)

There are three modes of WIFI:

0: Single AP mode it provides a hot spot for mobile Internet

1: Dual AP mode it provides two hotspots for mobile Internet

2: AP+STA mode it provides a hotspot for mobile Internet access, while providing a WIFI client to allow the module to connect to other routers

In general, if the WIFI mode of the device design is fixed, it is better to preset the WIFI mode.

Preset WIFI mode methods:

- Modify the nodes in `sim_open_sdk/sim_usrfs/mobileap_cfg.xml` and `sim_open_sdk/sim_rootfs/etc/default_mobileap_cfg.xml`:
- `<WlanMode>AP-AP</WlanMode>` value:

AP mode: AP

Dual AP mode: AP-AP

AP+STA mode: AP-STA

- modify `sim_open_sdk/sim_usrfs/mobileap_enable_cfg` value

AP mode: 0

AT+AP mode: 1

AP+STA mode: 2

Note: a and b models must be consistent.

If the WIFI mode of the device needs to be dynamically switched according to the scenario, you can call the following interface to adjust:

<b>Interface</b>	wifi_mode_type set_wifi_mode(wifi_mode_type mode)
<b>Input</b>	mode: wifi_mode_type 0: single AP mode 1: Dual AP mode

	2: AP+STA mode
<b>Output</b>	None
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	

### 3.15.3 WIFI Power

<b>Interface</b>	boolean wifi_power(int act)
<b>Input</b>	act: int type 1: open 0: close
<b>Output</b>	None
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	

### 3.15.4 Get WIFI status

<b>Interface</b>	boolean get_wifi_status(uint8 *flag)
<b>Input</b>	None
<b>Output</b>	flag: uint8 *type: 1: open 0: close
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	

### 3.15.5 Set WIFI hotspot name

<b>Interface</b>	boolean set_ssid(char *SSID, ap_index_type ap_index)
<b>Input</b>	1. SSID: Char*type Hotpot name string 2. ap_index: ap_index_type AP mode, 1

	AP-AP mode, 0 or 1 STA-AP mode, 2
<b>Output</b>	
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	

### 3.15.6 Get WIFI hotspot name

<b>Interface</b>	boolean get_ssid(char *str_SSID, ap_index_type ap_index)
<b>Input</b>	ap_index: ap_index_type AP mode, 1 AP-AP mode, 0 or 1 STA-AP mode, 2
<b>Output</b>	SSID: Char*type Hotpot name string
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	

### 3.15.7 Set AP auth type, encrypt mode, password

<b>Interface</b>	boolean set_auth(char *str_pwd, int auth_type, int encrypt_mode, ap_index_type ap_index)
<b>Input</b>	1. str_pwd: char*type password 2. auth_type: int type auth type 3. encrypt_mode: int type encrypt mode 4. ap_index: ap_index_type AP mode, 1 AP-AP mode, 0 or 1 STA-AP mode, 2
<b>Output</b>	None
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	1.When the auth type input is 0 or 1, the input value of the encrypt mode is 0 or 1;

2. When the auth type input is 2, the input value of encrypt mode can only be 1;

3. When the input value of the auth type is greater than 3, the input value of the encrypt mode must be greater than or equal to 2;

4. When the encrypt mode input is 0, it does not need to enter the password;

5. When the encrypt mode input is 1, the password must be entered.  
The format of the password input must satisfy: an ASCII encoded string of length 5 or 13 or a hexadecimal encoded string of length 10 or 26.

6. When the input value of the encrypt mode is greater than or equal to 2, the password must be input.  
The format of the password input must satisfy: an ASCII encoded string of length 8 to 63 or a hexadecimal encoded string of length 64.

Default value :

```
int authType = 5;
int encryptMode = 4;
ap_index_type: 0-> ap
                0-> ap & ap
                2-> ap & sta
```

### 3.15.8 Get AP auth type, encrypt mode, password

<b>Interface</b>	boolean get_auth(int *auth_type_ptr, int *encrypt_mode_ptr, char *pwd_str, ap_index_type ap_index)
<b>Input</b>	ap_index: ap_index_type AP mode, 1 AP-AP mode, 0 or 1 STA-AP mode, 2
<b>Output</b>	1. authType: int*type 2. encrypt_mode_ptr: int*type 3. pwd_str: char*type
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	

### 3.15.9 Set up WIFI broadcast switch

<b>Interface</b>	boolean set_bcast(int broadcast, ap_index_type ap_index)
<b>Input</b>	1. Broadcast: int type

	2. ap_index: ap_index_type AP mode, 1 AP-AP mode, 0 or 1 STA-AP mode, 2
<b>Output</b>	None
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	

### 3.15.10 Get WIFI broadcast settings

<b>Interface</b>	boolean get_bcast(int *broadcast, ap_index_type ap_index)
<b>Input</b>	ap_index: ap_index_type AP mode, 1 AP-AP mode, 0 or 1 STA-AP mode, 2
<b>Output</b>	Broadcast: int type
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	

### 3.15.11 Get DHCP settings

<b>Interface</b>	boolean get_dhcp(char *host_ip_str, char *start_ip_str, char *end_ip_str, char *time_str)
<b>Input</b>	None
<b>Output</b>	1. host_ip_str: host address 2. start_ip_str: start address 3. end_ip_str: end address 4. time_str: Authorization time
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	

### 3.15.12 Get the number of connected clients

<b>Interface</b>	int get_client_count(ap_index_type ap_index)
<b>Input</b>	ap_index: ap_index_type AP mode, 1 AP-AP mode, 0 or 1 STA-AP mode, 2
<b>Output</b>	None
<b>Return value</b>	Int type, Number of clients connected to AP
<b>NOTE</b>	

### 3.15.13 Get IP Address in STA Mode

<b>Interface</b>	Boolean get_sta_ip(char *ip_str, int len)
<b>Input</b>	None
<b>Output</b>	Ip_str: IP address
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	

### 3.15.14 Get WIFI MACaddress

<b>Interface</b>	boolean get_mac_addr(char *mac_addr, ap_index_type ap_index)
<b>Input</b>	ap_index: ap_index_type AP mode, 1 AP-AP mode, 0 or 1 STA-AP mode, 2
<b>Output</b>	mac_addr: char*type, mac address    The first one is HOST MAC
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	

### 3.15.15 Set IP obtained after the STA connects to the external hotspot

<b>Interface</b>	boolean get_sta_ip(char *ip_str, int len)
<b>Input</b>	None
<b>Output</b>	Ip_str: ip address

<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	

### 3.15.16 SetSTA's SSID and Password for Connecting to an External AP

<b>Interface</b>	boolean set_sta_cfg(char *ssid_str, char *psk_value)
<b>Input</b>	1. ssid_str: hotspot name 2. psk_value: password
<b>Output</b>	None
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	

### 3.15.17 Get SSID and password set by the STA

<b>Interface</b>	boolean get_sta_cfg(char *ssid_str, char *psk_value)
<b>Input</b>	None
<b>Output</b>	1. ssid_str: hotspot name 2. psk_value: password
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	

### 3.15.18 WIFI sta Scan available hotspots

<b>Interface</b>	boolean sta_scan(char *list_str)
<b>Input</b>	None
<b>Output</b>	list_str: list of available hotspots
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	

### 3.15.19 Set username and password for dialing in cdma mode

<b>Interface</b>	boolean set_user_name_pwd(char *sz_username, char *sz_usrpwd)
<b>Input</b>	1. sz_username: username 2. sz_usrpwd: password
<b>Output</b>	None
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	

### 3.15.20 Get username and password for dialing in cdma mode

<b>Interface</b>	boolean get_user_name_pwd(char *sz_username, int len_name, char *sz_usrpwd, int len_pwd)
<b>Input</b>	None
<b>Output</b>	1. sz_username: username 2. sz_usrpwd: password
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	

### 3.15.21 Get network status

<b>Interface</b>	boolean get_net_status(char *net_enable_str)
<b>Input</b>	None
<b>Output</b>	net_enable_str: network status
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	

### 3.15.22 Restore wifi settings

<b>Interface</b>	void restore_wifi()
<b>Input</b>	None

<b>Output</b>	None
<b>Return value</b>	None
<b>NOTE</b>	

### 3.15.23 Set hotspot name, auth type, encrypt mode, password

<b>Interface</b>	boolean set_ssid_and_auth(char *SSID, char *str_pwd, int auth_type, int encrypt_mode, ap_index_type ap_index)
<b>Input</b>	<ol style="list-style-type: none"> <li>1. SSID: Char* type Hotpot name string</li> <li>2.str_pwd: char* type Password</li> <li>3.auth_type: int type Auth type</li> <li>4.encrypt_mode: int type Encrypt mode</li> <li>5.ap_index: ap_index_type type AP mode, the value is 1 AP-AP mode, the value is 0 or 1 STA-AP mode, the value is 2</li> </ol>
<b>Output</b>	None
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>Interface</b>	boolean set_ssid_and_auth(char *SSID, char *str_pwd, int auth_type, int encrypt_mode, ap_index_type ap_index)

### 3.15.24 Open/close STA mode (for W58L)

<b>Interface</b>	boolean sta_init(int sta_enable)
<b>Input</b>	sta_enable: int type 0–close STA mode 1–open STA mode
<b>Output</b>	None
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	


### 3.15.25 Get the state of STA mode (for W58L)

<b>Interface</b>	boolean get_sta_status(uint8 *flag)
<b>Input</b>	None
<b>Output</b>	Flag: uint8 * type 1 – opened 0 – closed
<b>Return value</b>	Boolean type: TRUE or FALSE
<b>NOTE</b>	

### 3.15.26 Get the operation result code


<b>Interface</b>	Uint8wifi_get_err_code()
<b>Input</b>	None
<b>output</b>	None
<b>Return value</b>	Uint8 type: 0– success 1– invalid parameter 2–malloc memory error 3–send/receive message error 4–open file error 5–read/write file error 6–invalid return value 7–invalid AP ID 8–get information error 9–not W58L 10–other error
<b>NOTE</b>	The result code retain the last operation result. You could call the API to get the current operation result code if call a API which return failed.

### 3.15.27 Description of STA-AP function



### 3.15.28 Description of AP-AP function

AP-AP function description refer to the following flow chart:



### 3.16 SPI

**SIM7600E-H:** SPI interface cannot be used on the standard version. You need to update the version that supports SPI. You can configure UART1 or UART2 as SPI. For details, please refer to the SIM7600 Open Linux UART & SPI Documentation. The module's SPI supports only the Master mode and does not support the Slave mode. After the SPI version is started, the /dev/spidev2.0 device node is generated. The default SPI interface can only connect to a single peripheral device.

### 3.17 USB OTG


It requires peripheral circuit design. Currently it only supports U disk. SDK is default support.

### 3.18 Bluetooth


It is recommended that customers select the W58 module and package the Qualcomm QCA9377 Bluetooth chip.

This chapter describes how to implement SPP data sending and receiving, GATT data transmission and etc. by calling the Bluetooth API.

SPP data send and receive data. First turn on Bluetooth. If you do not pair with the peer Bluetooth, you need to pair first. After the pairing is completed, start the SPP server for the peer Bluetooth connection or directly connect the peer Bluetooth SPP server to complete the data transfer.



Bluetooth SPP pairing and SPP data transceiver flow chart



GATT Data transceiver flow chart

The following is the relevant API interface in SPP function:

### 3.18.1 Bluetooth interface initialization

<b>Interface</b>	int Init(bt_ind_cb_fcn handle);
<b>Input</b>	typedef void (*bt_ind_cb_fcn)(void *pData); callback
<b>Output</b>	None

<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.18.2 Bluetooth power

<b>Interface</b>	int simcom_bt_power_on(int bPower);
<b>Input</b>	bPower          0: close          1: open
<b>Output</b>	None
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.18.3 Get paired list

<b>Interface</b>	int get_bonded_device(void);
<b>Input</b>	None
<b>Output</b>	Return the paired list in the callback function with the messageBT_BONDED_COMMAND The specific parameters of the message refer to callback function description
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.18.4 Search Bluetooth

<b>Interface</b>	int search_devices(int subcmd, int mode, int timeout);
<b>Input</b>	None
<b>Output</b>	The search list is returned in the callback function with the message BT_SEARCH_COMMAND The specific parameters of the message refer to callback function description
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.18.5 Bluetooth pairing

<b>Interface</b>	int search_devices(int subcmd, int mode, int timeout);
<b>Input</b>	index: Search index number in Bluetooth list
<b>Output</b>	The pairing confirmed notification is returned in the callback function with the message BT_ACCEPT_COMMAND or return the pairing result with message BT_BOND_COMMAND The specific parameters of the message refer to callback function description.
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.18.6 Pairing confirmation request

<b>Interface</b>	Init registered callback function
<b>Input</b>	None
<b>Output</b>	Report BT_ACCEPT_COMMAND message The specific parameters of the message refer to callback function description.
<b>Return value</b>	
<b>NOTE</b>	

### 3.18.7 Accept pairing

<b>Interface</b>	int accept_bond(int isAccept, accept_mode mode);
<b>Input</b>	isAccept: Whether to receive pairing mode: Pairing mode ACCEPT_MODE_NONE = 0 mode can be ignored when not accepted. ACCEPT_MODE_COMPARE = 1 Compare pairing password ACCEPT_MODE_PASSKEY = 2    Need to enter password ACCEPT_MODE_REBOND = 3    Re-pairing ACCEPT_MODE_NOTIFICATION = 4 Notice only, no reply required ACCEPT_MODE_JUSTWORK = 5 Pairing directly ACCEPT_MODE_PINCODE = 6 PIN pairing mode
<b>Output</b>	The pairing result is returned in the callback function with the message BT_BOND_COMMAND The specific parameters of the message refer to callback function

	description.
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	This interface is executed when the callback function BT_ACCEPT_COMMAND message is received.

### 3.18.8 Pairing results

<b>Interface</b>	Init registered callback function
<b>Input</b>	None
<b>Output</b>	Report BT_BOND_COMMAND message The specific parameters of the message refer to callback function description.
<b>Return value</b>	
<b>NOTE</b>	

### 3.18.9 Open SPP Server

<b>Interface</b>	int spp_server(int bActive);
<b>Input</b>	bActive:    1: open        0: close
<b>Output</b>	Return value
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	Determine whether to open or close successfully by the return value

### 3.18.10 Query whether the peer Bluetooth is enabled with SPP Server

<b>Interface</b>	int bt_get_profile(int index, int *isSupportSPP);
<b>Input</b>	index: Paired list index number
<b>Output</b>	isSupportSPP:        1: opened        0: Unopened
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.18.11 Initiate SPP connection

<b>Interface</b>	int spp_conncet_device(int index);
<b>Input</b>	index: Paired list index number
<b>Output</b>	Return value
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	Determine whether to open or close successfully by the return value

### 3.18.12 Cut SPP connection

<b>Interface</b>	int spp_disconnct_device(void);
<b>Input</b>	None
<b>Output</b>	Return value
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	Determine whether to open or close successfully by the return value

### 3.18.13 Non-active connect SPP

<b>Interface</b>	Init registered callback function
<b>Input</b>	None
<b>Output</b>	Report BT_CONNECT_COMMANDmessage The specific parameters of the message refer to callback function description.
<b>Return value</b>	
<b>NOTE</b>	

### 3.18.14 Non-active cut SPP connections

<b>Interface</b>	Init registered callback function
<b>Input</b>	None
<b>Output</b>	Report BT_DISCONNECT_COMMAND message The specific parameters of the message refer to callback function description.
<b>Return value</b>	

**NOTE**

### 3.18.15 Query the status of the local SPP server

<b>Interface</b>	int bt_get_server_status(int *isActive);
<b>Input</b>	None
<b>Output</b>	isActive      0: close      1: open
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.18.16 Query SPP connection status

<b>Interface</b>	int bt_get_connect_status(int *isConnected);
<b>Input</b>	None
<b>Output</b>	isConnected:    0: disconnect    1: connect
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.18.17 SPP send data

<b>Interface</b>	int spp_send_data(uint8_t *data, uint16_t data_len);
<b>Input</b>	Data          data data_len      length of data
<b>Output</b>	Return value
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.18.18 SPP receive data

<b>Interface</b>	Init registered callback function
<b>Input</b>	None
<b>Output</b>	Report BT_SPP_RECV_COMMAND message

	The specific parameters of the message refer to callback function description.
<b>Return value</b>	
<b>NOTE</b>	

### 3.18.19 Query local Bluetooth name and MAC address

<b>Interface</b>	int host_device(char *device_name, SIMCOM_BT_ADDR_T *paddr);
<b>Input</b>	None
<b>Output</b>	device_name name of bluetooth paddr           MAC address
<b>Return value</b>	0: success   -1: failure
<b>NOTE</b>	This interface is an overloaded function. Parameters are shown in this section as queries. If there is only one char * parameterset the Bluetooth address.

### 3.18.20 Set local Bluetooth name

<b>Interface</b>	int host_device(char *device_name);
<b>Input</b>	device_name   name of bluetooth
<b>Output</b>	None
<b>Return value</b>	0: success           -1: failure
<b>NOTE</b>	This interface is overloaded and parameters settings as shown in this section.

### 3.18.21 Set PIN code

<b>Interface</b>	int pin_set(char *pincode);
<b>Input</b>	pincode:   pin code4~16 digits Arabic string
<b>Output</b>	None
<b>Return value</b>	0: success   -1: failure
<b>NOTE</b>	The PIN code is a relatively unsafe mode that is easy to crack so it is not recommended. It is turned off by default. If the customer has special requirements, please refer to the demo start part of the source code to modify the Bluetooth boot parameters.

### 3.18.22 Read PIN code

<b>Interface</b>	int pin_read(char *pincode);
<b>Input</b>	None
<b>Output</b>	pincode
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.18.23 Set BR/EDR inquiry scan and page scan

<b>Interface</b>	int bt_set_scan_enable(int inquiry_scan_status, int page_scan_status);
<b>Input</b>	inquiry_scan_status    0: close    1: open page_scan_status        0: close    1: open
<b>Output</b>	None
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	inquiry_scan: If closed, other Bluetooth devices will not find this Bluetooth page_scan: If closed, other Bluetooth will not be able to connect to this Bluetooth

### 3.18.24 Query BR/EDR inquiry scan and page scan settings

<b>Interface</b>	int bt_set_scan_enable(int inquiry_scan_status, int page_scan_status);
<b>Input</b>	None
<b>Output</b>	inquiry_scan_status    0: close    1: open page_scan_status        0: close    1: open
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	inquiry_scan: If closed, other Bluetooth devices will not find this Bluetooth page_scan: If closed, other Bluetooth will not be able to connect to this Bluetooth

### 3.18.25 GATT registration

<b>Interface</b>	int bt_gatt_register(int bRegister);
<b>Input</b>	bRegister: 1: register 0: Unregister
<b>Output</b>	None
<b>Return value</b>	0: success -1: failure
<b>NOTE</b>	

### 3.18.26 Create database

<b>Interface</b>	int bt_gatt_createdatabase(int bCreateDb);
<b>Input</b>	bCreateDb 1: create 0: delete
<b>Output</b>	None
<b>Return value</b>	0: success -1: failure
<b>NOTE</b>	

### 3.18.27 Create 16-bit UUID service

<b>Interface</b>	int bt_gatt_create_service(int uuid16);
<b>Input</b>	uuid16 16bit UUID
<b>Output</b>	None
<b>Return value</b>	0: success -1: failure
<b>NOTE</b>	This interface is a heavy load interface.

### 3.18.28 Create 128-bit UUID service

<b>Interface</b>	int bt_gatt_create_service(unsigned char *uuid128);
<b>Input</b>	uuid128 128bit UUID
<b>Output</b>	None
<b>Return value</b>	0: success -1: failure
<b>NOTE</b>	This interface is a heavy load interface.

### 3.18.29 Create 16-bit characteristics

<b>Interface</b>	int bt_gatt_create_characteristic(int uuid16, int pro, int permission, uint32_t *attrHandle);
<b>Input</b>	uuid16          16-bit UUID pro                property permission       authority
<b>Output</b>	None
<b>Return value</b>	0: success      -1: failure
<b>NOTE</b>	This interface is a heavy load interface.

### 3.18.30 Create 128-bit characteristics

<b>Interface</b>	int bt_gatt_create_characteristic(unsigned char *uuid128, int pro, int permission, uint32_t *attrHandle);
<b>Input</b>	uuid128          128-bit UUID pro                property permission       authority
<b>Output</b>	None
<b>Return value</b>	0: success      -1: failure
<b>NOTE</b>	This interface is a heavy load interface.

### 3.18.31 Create a descriptor

<b>Interface</b>	int bt_gatt_create_descriptor();
<b>Input</b>	None
<b>Output</b>	None
<b>Return value</b>	0: success      -1: failure
<b>NOTE</b>	This interface is currently configured for perfection so use the default configuration temporarily.

### 3.18.32 Add the created service to the database

<b>Interface</b>	int bt_gatt_add_service_2_db();
<b>Input</b>	None
<b>Output</b>	None
<b>Return value</b>	0: success      -1: failure

**NOTE**

### 3.18.33 Send notification

<b>Interface</b>	int bt_gatt_notification(uint16_t attrhandle, char *data, uint32_t data_len);
<b>Input</b>	attrhandle attribute handle data data data_len data length
<b>Output</b>	None
<b>Return value</b>	0: success -1: failure
<b>NOTE</b>	

### 3.18.34 Send indication

<b>Interface</b>	int bt_gatt_indication (uint16_t attrhandle, char *data, uint32_t data_len);
<b>Input</b>	attrhandle attribute handle data data data_len data length
<b>Output</b>	None
<b>Return value</b>	0: success -1: failure
<b>NOTE</b>	

### 3.18.35 Return host reads data from local request

<b>Interface</b>	int bt_gatt_read_cfm(uint16_t attrHandle, int rspCode, uint8_t *data, uint32_t data_len);
<b>Input</b>	attrhandle attribute handle rspCode error code data data data_len data length
<b>Output</b>	None
<b>Return value</b>	0: success -1: failure
<b>NOTE</b>	

### 3.18.36 Return the host to write data requests from the local

<b>Interface</b>	int bt_gatt_write_cfm(uint16_t attrHandle, int rspCode);
<b>Input</b>	attrhandleattribute handle rspCodeerror code
<b>Output</b>	None
<b>Return value</b>	0: success    -1: failure

### 3.18.37 Callback

```
static void simcom_process_response(bt_msg *recv_msg)
{
switch(recv_msg->command)
{
case BT_SEARCH_COMMAND:
Scan result output
param1: search status: search end
param2: search result index
param3: rssi;
address: device mac address
data_len: data name length
data: device name
break;
case BT_BOND_COMMAND:
Pairing returns results
param1: bond result 0: FAILED 1:SUCCESS
address: device mac address
data_len device name length
data: if data_len > 0 deviceName
break;
case BT_ACCEPT_COMMAND:
Prompt the user to confirm the pairing
param1: accept mode
param2: if ((param1 == ACCEPT_MODE_NOTIFICATION) ||
(param1 == ACCEPT_MODE_COMPARE) ||
(param1 == ACCEPT_MODE_PASSKEY))

param2 is passkey value
else
ignore
address: device address
data_len: data length
```

```
data:    device name  (maybe null)
break;
case BT_GET_BONDED_COMMAND:
Get a list of paired devices
param1 = total bonded number
param2 = current index;
param3 :  if total bonded unumber more than 0,  1: last one
address = devices;          break;

case BT_CONNECT_COMMAND:
        Report the message that other Bluetooth devices via SPP connection module.
break;

case BT_DISCONNECT_COMMAND:
        Report the message that non-module actively disconnect SPP connection.
break;

case BT_SPP_RECV_COMMAND:
SPP  Receive data
data_len:  receive data len
data:     receive data
break;

case BT_GATT_CONNECT_COMMAND:
        Report the message thatGATT has connected.
break;
case BT_GATT_READ_IND_COMMAND:
        Report the message that other devices try to read module data via Bluetooth.
break;
case BT_GATT_WRITE_IND_COMMAND:
        Report the message that other devices try to write module data via Bluetooth.
break;
    }
}
```

## 3.19 ETH

### 3.19.1 Network card mode settings

Ethernet is divided into three modes:

0: ETH\_LAN Peripherals access the module through the Internet and the peripheral IP is allocated via the HDCP module.

1: ETH\_WAN The module accesses the Internet via Ethernet.

2: ETH\_LAN\_STATIC Peripherals access the Internet through the module. Module ETH and peripheral IP set to static IP

In general, the functionality of Ethernet is pre-defined at design time. So you can set the mode before compiling the SDK. Modify the preset mode by modifying the value of the SDK source `mdm-init/wlan/lan_mode`. The corresponding value of the pattern is the above list value.

If the client is using windows development, downloading the default file to the system using the tool requires downloading two files: Copy 'lan\_mode' and change the name to 'default\_lan\_mode'.

Download 'default\_lan\_mode' to 'etc' directory and download 'lan\_mode' to 'data' directory. 'Default\_lan\_mode' is used to restore when the file in the data directory is destroyed.

The dynamic switching mode can set the network mode with `AT+CLANMODE=0/1/2` command. However, this setting only modifies the `lan_mode` value in the data directory. If the `lan_mode` in the data directory is destroyed, it will revert to the default value (`default_lan_mode` value). Therefore, if the ETH mode designed by the customer is fixed, it is recommended to directly preset the initial mode.

### 3.19.2 Network card mode selection

<b>Interface</b>	Init(ethernet_type_info type)
<b>Input</b>	type 1 BCM898XX 2 AT803X
<b>Output</b>	None
<b>Return value</b>	0: success -1: failure

### 3.19.3 Driver install

<b>Interface</b>	int Install_driver()
<b>Input</b>	None
<b>Output</b>	None
<b>Return value</b>	0: success -1: failure

### 3.19.4 Driver uninstall

<b>Interface</b>	int Uninstall_driver()
<b>Input</b>	None
<b>Output</b>	None
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	If sleep needs to uninstall Ethernet driver.

### 3.19.5 Read preset MAC address from NV

<b>Interface</b>	int get_mac_address_from_nv(dms_device_mac_enum_v01 device_type, uint8_t *mac_addr);
<b>Input</b>	DMS_DEVICE_MAC_WLAN_V01 = 0    ---- WIFI MAC address DMS_DEVICE_MAC_BT_V01    = 1    ---- Bluetooth MAC address DMS_DEVICE_MAC_LAN_V01 = 2    ---- ETH    MAC address
<b>Output</b>	None
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.19.6 Set MAC address

<b>Interface</b>	int set_eth_mac_address(char *mac_address)
<b>Input</b>	mac_address:    MAC address stringFor example: 64:00:6A:04:65:A1
<b>Output</b>	None
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	If the MAC address is not read in NV, a random value can be set.


### 3.19.7 Set IP

<b>Interface</b>	int set_eth_ip_address(char *ip_address)
<b>Input</b>	ip_address:    IP address:    192.168.*.*
<b>Output</b>	None
<b>Return value</b>	None
<b>NOTE</b>	Module sleep needs to uninstall ETH driver.

## 3.20 Network settings

This section mainly introduces the network access modes and network settings supported by the module.

## 3.21 Network access methods



There are three main ways to access the external network module:

1. Mobile network
2. WIFI\_STA/WIFI opens STA
3. ETH\_WAN/Ethernet as WAN port

There are four ways to connect external devices:

1. WIFI\_AP
2. RNDIS
3. ETH\_LAN Ethernet is connected to the internal bridge0 of the module. The module automatically assigns IP to the device.
4. ETH\_LAN\_STATIC Both the Ethernet module and the Ethernet port on the master device are set static IP.

The first three modes: The connection between the master device and the module is connected in the form of a local area network. A 192.168.225.\* IP will be obtained from module HDCP. After the IP is successfully obtained the master can connect to the external network through the module, and can also communicate with the internal process of the module (APP) through the LAN IP.

The last mode: It needs to be set by the customer APP and the master to set the IP, gateway, NDS.

IP: 192.168.\*.\* (Same network segment as IP set by APP to ETH\_LAN\_STATIC)

Gateway: 192.168.\*.\* (Same as the IP set by the APP for ETH\_LAN\_STATIC)

DNSserver: 192.168.225.1 (regular)

### 3.21.1 Default route priority preset

Modify the nodes in `sim_open_sdk/sim_usrfs/mobileap_cfg.xml` and `sim_open_sdk/sim_rootfs/etc/default_mobileap_cfg.xml`:

```
<FirstPreferredBackhaul>usb_cradle</FirstPreferredBackhaul>
<SecondPreferredBackhaul>wlan</SecondPreferredBackhaul>
  <ThirdPreferredBackhaul>wwan</ThirdPreferredBackhaul>
usb_cradle: Ethernet (ETH_WAN)
wlan: WLAN_STA
wwan: Mobile network
```

The module selects a default route based on the current module status and profile settings.

For example:

In the current setting, when the module has both WLAN\_STA and ETH\_WAN connected, the default route will be set to ETH\_WAN. This means that accessing the external network will be accessed via ETH.

The setting does not change. If the Ethernet cable is unplugged, the default route will become WLAN. Insert the Ethernet cable. After the Ethernet connection is successful, the default route will be switched to ETH\_WAN.

If the customer wants to use ETH\_WAN preferentially when both WLAN\_STA and ETH\_WAN are connected, their order can be adjusted. Similarly, if the customer wants to pass 4G network when the 4G network dials successfully, then jump the 4G priority to the highest.

## 3.22 ALSA

### 3.22.1 Set the volume of inner speaker

<b>Interface</b>	int set_clvl_value(int clvl_value)
<b>Input</b>	clvl_value: volume value (0-5)
<b>Output</b>	None
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.22.2 Get the volume fo inner speaker

<b>Interface</b>	int get_clvl_value(void)
<b>Input</b>	None
<b>Output</b>	None
<b>Return value</b>	-1: failure    volume value: success
<b>NOTE</b>	

### 3.22.3 Set the mic gain

<b>Interface</b>	int set_micgain_value(int micgain_value)
<b>Input</b>	micgain_value: the gain value to be set(0-8)
<b>Output</b>	None
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.22.4 Get the mic gain

<b>Interface</b>	int get_micgain_value(void)
<b>Input</b>	None
<b>Output</b>	None

<b>Return value</b>	The mic gain value: success    -1: failure
<b>Interface</b>	int get_micgain_value(void)

### 3.22.5 Switch voice channel

<b>Interface</b>	int set_csdvc_value(int csdvc_value)
<b>Input</b>	csdvc_value 1: handset 3: speaker
<b>Output</b>	None
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.22.6 Query the current voice channel

<b>Interface</b>	int get_csdvc_value(void)
<b>Input</b>	None
<b>Output</b>	None
<b>Return value</b>	The integer fo current voice channel: success    -1: failure
<b>NOTE</b>	

## 3.23 Device Control

### 3.23.1 Enter the recovery mode

<b>Interface</b>	int exec_cdelta_cmd(const char *path)
<b>Input</b>	Path specifies the path of the upgrade package. It will use the default path(/cache/update_ota.zip) when path is NULL.
<b>output</b>	None
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.23.2 adb setting

<b>Interface</b>	int exec_cusbadb_cmd(bool value)
<b>Input</b>	value 1: open adb port 0: close adb port
<b>Output</b>	None
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

## 3.24 DMS

### 3.24.1 Initialization

<b>Interface</b>	int dms_init()
<b>Input</b>	None
<b>Output</b>	None
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.24.2 Get imei

<b>Interface</b>	int get_imei(char *plmei)
<b>Input</b>	plmei : the buffer pointer to cache the imei
<b>Output</b>	None
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.24.3 Get meid

<b>Interface</b>	int get_meid(char *pMeid);
<b>Input</b>	pMeid: the buffer pointer to cache the meid
<b>Output</b>	None
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.24.4 Get the firmware version identification code

<b>Interface</b>	int get_rev_id(char *pRev_id)
<b>Input</b>	pRev_id: the buffer pointer to cache the Rev_id
<b>Output</b>	None
<b>Return value</b>	0: success
<b>Interface</b>	int get_rev_id(char *pRev_id)

### 3.24.5 Set the UE work mode

<b>Interface</b>	int dms_set_operating_mode(unsigned char mode)
<b>Input</b>	mode: 0 Online 1 Low power 2 Factory Test mode 3 Offline 4 Resetting 5 Shutting down 6 Persistent low power 7 Mode-only low power
<b>Output</b>	None
<b>Return value</b>	0: success    -1: failure
<b>NOTE</b>	

### 3.24.6 Release

<b>Interface</b>	void dms_deinit()
<b>Input</b>	None
<b>output</b>	None
<b>Return value</b>	none
<b>NOTE</b>	

SIMCom  
Confidential

## 4. Customer version maintenance

The customer version is saved in the file `/etc/simcom_ap_ver.ini`; the max length of the version string is 35 bytes. It can query the version information through the following methods:

- 1) Cat the file content.
- 2) Call `AT+CSUB=1`.

SIMCom  
Confidential