



SIM7500_SIM7600_SIM7800 Series_TCPIP_Application Note

LTE Module

SIMCom Wireless Solutions Limited

SIMCom Headquarters Building, Building 3, No. 289
Linhong Road, Changning District, Shanghai P.R. China

Tel: 86-21-31575100

support@simcom.com

www.simcom.com

Document Title:	SIM7500_SIM7600_SIM7800 Series _TCPIP_Application Note
Version:	3.00
Date:	2022.02.08
Status:	Released

GENERAL NOTES

SIMCOM OFFERS THIS INFORMATION AS A SERVICE TO ITS CUSTOMERS, TO SUPPORT APPLICATION AND ENGINEERING EFFORTS THAT USE THE PRODUCTS DESIGNED BY SIMCOM. THE INFORMATION PROVIDED IS BASED UPON REQUIREMENTS SPECIFICALLY PROVIDED TO SIMCOM BY THE CUSTOMERS. SIMCOM HAS NOT UNDERTAKEN ANY INDEPENDENT SEARCH FOR ADDITIONAL RELEVANT INFORMATION, INCLUDING ANY INFORMATION THAT MAY BE IN THE CUSTOMER'S POSSESSION. FURTHERMORE, SYSTEM VALIDATION OF THIS PRODUCT DESIGNED BY SIMCOM WITHIN A LARGER ELECTRONIC SYSTEM REMAINS THE RESPONSIBILITY OF THE CUSTOMER OR THE CUSTOMER'S SYSTEM INTEGRATOR. ALL SPECIFICATIONS SUPPLIED HEREIN ARE SUBJECT TO CHANGE.

COPYRIGHT

THIS DOCUMENT CONTAINS PROPRIETARY TECHNICAL INFORMATION WHICH IS THE PROPERTY OF SIMCOM WIRELESS SOLUTIONS LIMITED COPYING, TO OTHERS AND USING THIS DOCUMENT, ARE FORBIDDEN WITHOUT EXPRESS AUTHORITY BY SIMCOM. OFFENDERS ARE LIABLE TO THE PAYMENT OF INDEMNIFICATIONS. ALL RIGHTS RESERVED BY SIMCOM IN THE PROPRIETARY TECHNICAL INFORMATION, INCLUDING BUT NOT LIMITED TO REGISTRATION GRANTING OF A PATENT , A UTILITY MODEL OR DESIGN. ALL SPECIFICATION SUPPLIED HEREIN ARE SUBJECT TO CHANGE WITHOUT NOTICE AT ANY TIME.

SIMCom Wireless Solutions Limited

SIMCom Headquarters Building, Building 3, No. 289 Linhong Road, Changning District, Shanghai P.R. China

Tel: +86 21 31575100

Email: simcom@simcom.com

For more information, please visit:

<https://www.simcom.com/download/list-863-en.html>

For technical support, or to report documentation errors, please visit:

<https://www.simcom.com/ask/> or email to: support@simcom.com

Copyright © 2022 SIMCom Wireless Solutions Limited All Rights Reserved.

About Document

Version History

Version	Date	Owner	What is new
V2.00	2020.8.6	Yulong Li	Update the format
V3.00	2022.02.08	Haotian Wang	Update the format

Scope

This document applies to SIM7500 series SIM7600 series and SIM7800 series.

Contents

About Document	3
Version History.....	3
Scope.....	3
Contents	4
1 Introduction	5
1.1 Purpose of the document.....	5
1.2 Related documents.....	5
1.3 Conventions and abbreviations.....	5
2 TCPIP Introduction	6
2.1 Characteristic.....	6
2.2 TCPIP Commands Process.....	7
3 AT Commands for TCPIP	8
4 Bearer Configuration	9
4.1 Start TCPIP Service.....	9
5 TCPIP Examples	11
5.1 TCP Client.....	11
5.1.1 TCP Client Works in Direct Push Mode.....	11
5.1.2 TCP Client Works in Buffer Access Mode.....	12
5.1.3 TCP Client Works in Transparent Access Mode.....	13
5.2 UDP Client.....	14
5.2.1 UDP Client Works in Direct Push Mode.....	15
5.2.2 UDP Client Works in Buffer Access Mode.....	16
5.2.3 UDP Client Works in Transparent Access Mode.....	17
5.3 TCP Server.....	18
5.3.1 Transparent Mode.....	19
5.3.2 Non-Transparent Mode.....	19
5.4 Extended Information.....	21
5.4.1 UDP Data Receiving Rules.....	21
5.5 Query Connection Status.....	21

1 Introduction

1.1 Purpose of the document

Based on module AT command manual, this document will introduce TCPIP application process.

Developers could understand and develop application quickly and efficiently based on this document.

1.2 Related documents

[1] SIM7500_SIM7600 Series_AT Command Manual

1.3 Conventions and abbreviations

Abbreviation	Description
TCP	Transmission Control Protocol
UDP	User Datagram Protocol

2 TCPIP Introduction

TCPIP is used to setup connections between clients and servers, which are used for TCP/UDP clients communicating with servers.

2.1 Characteristic

➤ **Support connecting TCP/UDP servers;**

✧ **TCP connections**

Module works as TCP clients. It communicates with TCP servers by TCP connections.

✧ **UDP connections**

Module works as UDP clients. It communicates with UDP servers.

➤ **Support accepting TCP clients;**

✧ **TCP servers**

Module works as TCP servers. It listens TCP clients accept request and communicates with TCP clients.

➤ **Support multiple data transmission mode;**

✧ **Direct Push Mode**

Host data will be sent to internal protocol stack and forwarded to air interface. Data received from air interface will be transmitted to internal protocol stack and forwarded to COM ports.

✧ **Buffer Access Mode**

Host data will be sent to internal protocol stack and forwarded to air interface. Data received from air interface will be saved into local buffers. Host could retrieve buffer data by AT commands.

✧ **Transparent Access Mode**

Host data will be directly sent to air interface. Data received from air interface will be directly sent to COM ports.

2.2 TCPIP Commands Process




Figure 1: Flow Chart of Using TCP/IP Commands

3 AT Commands for TCPIP

Command	Description
AT+NETOPEN	Start TCPIP Service
AT+NETCLOSE	Stop TCPIP Service
AT+CIOPEN	Setup TCP/UDP Client Socket Connections
AT+CIPCLOSE	Destroy TCP/UDP Client Socket Connections
AT+CIPSEND	Send TCP/UDP Data
AT+CIPRXGET	Retrieve TCP/UDP Buffer Data
AT+IPADDR	Get IP Address of PDP Context
AT+CIPHEAD	Set Length Domain of Reporting Head of Data
AT+CIPSRIP	Set IP Domain of Reporting Head of Data
AT+CIPMODE	Enable/Disable Transparent Access Mode
AT+CIPSENDMODE	Set Reporting Mode of CIPSEND result
AT+CIPTIMEOUT	Set Timeout Value of NETOPEN, CIOPEN and CIPSEND
AT+CIPCCFG	Configure Socket Context
AT+SERVERSTART	Setup TCP Server Socket Connections
AT+SERVERSTOP	Destroy TCP Server Socket Connections
AT+CIPACK	Get Statistics Information of Data Communication
AT+CDNSGIP	Analysis IP Address from Domain Name
AT+CDNSGHNAME	Analysis Domain Name from IP Address
AT+CIPDNSSET	Configure DNS Context

For detail information, please refer to SIM7500_SIM7600 Series AT Command Manual document.

4 Bearer Configuration

Module will usually attach to network and register PS service automatically.

4.1 Start TCPIP Service

//Example of PDN Auto-activation.

AT+CPIN?

+CPIN: READY //Check Status of SIM Card

OK

AT+CSQ

+CSQ: 27,99 //Check RF Signal

OK

AT+CGREG?

+CGREG: 0,1 //Check Status of PS Service

OK

AT+COPS?

+COPS: 0,0,"CHN-UNICOM",7 //Check Information of Operator

OK

AT+CPSI?

+CPSI:

LTE,Online,460-00,0x1816,27593
483,139,EUTRAN-BAND39,38400,
5,5,-88,-868,-578,18 //Check Information of Network

OK

AT+CGDCONT?

+CGDCONT:

1,"IPV4","CMNET","0.0.0.0.0.0.0.
0.0.0.0.0.0.0.0",0,0,0,0 //Check Information of PDP Context

OK

AT+CGDCONT=1, "IP", "CMNET"

```
OK //Set PDP Context
AT+NETOPEN
OK
+NETOPEN: 0 //Start TCPIP Service
```

SIMCom
Confidential

5 TCPIP Examples

5.1 TCP Client

5.1.1 TCP Client Works in Direct Push Mode

5.1.1.1 Set up TCP Client Connection

```
AT+NETOPEN
```

```
OK
```

```
+NETOPEN: 0
```

```
AT+CIPOPEN=1,"TCP","117.131.85.139",5253
```

```
// Set up a TCP connection, <link_num> is 1.
```

```
// Before using AT+CIPOPEN, host should
```

```
// activate PDP ontext with AT+NETOPEN first.
```

```
OK
```

```
+CIPOPEN: 1,0
```

5.1.1.2 Send data to Server

```
AT+CIPSEND=1,5
```

```
// send data with fixed length
```

```
>HELLO
```

```
OK
```

```
+CIPSEND: 1,5,5
```

```
AT+CIPSEND=1,
```

```
// send data with changeable length, <CTRL+Z>
```

```
// to end
```

```
>HELLOWORLD<CTRL+Z>
```

```
OK
```

```
+CIPSEND: 1,10,10
```

5.1.1.3 Receive Data From Server

```
RCV FROM:117.131.85.139:5253
```

```
// data from server directly output to COM
```

```
+IPD16
```

```
data from server
```

5.1.1.4 Close TCP Connection

```
AT+CIPCLOSE=1
```

```
OK
```

```
+CIPCLOSE: 1,0
```

5.1.2 TCP Client Works in Buffer Access Mode

5.1.2.1 Set up TCP Client connection

```
AT+NETOPEN
```

```
OK
```

```
+NETOPEN: 0
```

```
AT+CIPRXGET=1 // buffer access mode, get data by AT+CIPRXGET
```

```
OK
```

```
AT+CIOOPEN=1,"TCP","117.131.85.139",5253 // set up a TCP connection, <link_num> is 1
```

```
OK
```

```
+CIOOPEN: 1,0
```

5.1.2.2 Send Data to Server

```
AT+CIPSEND=1,5 // send data with fixed length
```

```
>hello
```

```
OK
```

```
+CIPSEND: 1,5,5
```

5.1.2.3 Receive Data from Server

```
+CIPRXGET: 1,1 // URC to notify host of data from server
```

```
AT+CIPRXGET=4,1 // query the length of data in the buffer of socket with <link_num>=1
```

```
+CIPRXGET: 4,1,16
```

```
OK
```

```
AT+CIPRXGET=2,1,5 // get data in ASCII form
```

```
+CIPRXGET: 2,1,5,11
```

```
data
```

```
OK
```

```
AT+CIPRXGET=3,1,5 // get data in hex form
+CIPRXGET: 3,1,5,6
66726F6D20

OK
AT+CIPRXGET=4,1 // read the length of unread data in buffer
+CIPRXGET: 4,1,6

OK
AT+CIPRXGET=2,2 // the connection identified by link_num=2 has not been established
+IP ERROR: No data

ERROR
AT+CIPRXGET=2,1
+CIPRXGET: 2,1,6,0
server

OK
AT+CIPRXGET=4,1 // all the data in buffer has been read, the rest_len is 0.
+CIPRXGET: 4,1,0

OK
```

5.1.2.4 Close TCP Connection

```
AT+CIPCLOSE=1
OK

+CIPCLOSE: 1,0
```

5.1.3 TCP Client Works in Transparent Access Mode

5.1.3.1 Set up TCP Client Connection

```
AT+CIPMODE=1 // Enter into transparent mode by at+cipmode=1
OK
AT+NETOPEN
OK

+NETOPEN: 0
AT+CIOPEN=0,"TCP","117.131.85.139",5253 // only <link_num>=0 is allowed to operate with
```

// transparent mode.

CONNECT 115200

5.1.3.2 Send Data to Server

All data got from com port will be sent to internet directly

5.1.3.3 Receive Data From Server

DATA FROM SERVERDATA FROM SERVER // all the received data from server will be output to
// com port directly
// sequence of +++ to quit transparent mode

OK

AT+CIOPEN?

+CIOPEN: 0,"TCP","117.131.85.139",5253,-1

+CIOPEN: 1

+CIOPEN: 2

+CIOPEN: 3

+CIOPEN: 4

+CIOPEN: 5

+CIOPEN: 6

+CIOPEN: 7

+CIOPEN: 8

+CIOPEN: 9

OK

ATO

// ATO to enter transparent mode again

CONNECT 115200

HELLO CLIENT

5.1.3.4 Close TCP Connection

AT+CIPCLOSE=0

OK

CLOSED

+CIPCLOSE: 0,0

5.2 UDP Client

5.2.1 UDP Client Works in Direct Push Mode

5.2.1.1 Set up UDP Client Connection

AT+NETOPEN

OK

+NETOPEN: 0

AT+CIPOPEN=1,"UDP",,,5000

// when set a UDP connection, the remote IP
// address and port is not necessary, but the local
// port must be specified.

+CIPOPEN: 1,0

OK

5.2.1.2 Send data to Server

AT+CIPSEND=1,"117.131.85.139",5254

// for UDP connection, when sending data, user must
// specify the remote IP address and port. Sending data
// with changeable length

>HELLOSERVER

OK <CTRL+Z>

// <CTRL+Z> to end

+CIPSEND: 1,11,11

AT+CIPSEND=1,5,"117.131.85.139",5254

// send data with fixed length

>HELLO

OK

+CIPSEND: 1,5,5

5.2.1.3 Receive Data From Server

RCV FROM:117.131.85.139:5254

// data from server output to COM port directly

+IPD14

HELLO CLIENT

5.2.1.4 Close UDP Connection

AT+CIPCLOSE=1

+CIPCLOSE: 1,0

OK

5.2.2 UDP Client Works in Buffer Access Mode

5.2.2.1 Set up UDP Client connection

AT+NETOPEN

OK

+NETOPEN: 0

AT+CIPRXGET=1

// buffer access mode, get data by AT+CIPRXGET

OK

AT+CIOPEN=1,"UDP",,,5000

// when set a UDP connection, the remote IP address and
// port is not necessary, but the local port must be specified.

+CIOPEN: 1,0

OK

5.2.2.2 Send Data to Server

AT+CIPSEND=1,,"117.131.85.139",5254

// for UDP connection, when sending data, user must
// specify the remote IP address and port. Sending data
// with changeable length, <CTRL+Z> to end

>HELLOSERVER

OK <CTRL+Z>

+CIPSEND: 1,11,11

AT+CIPSEND=1,5,"117.131.85.139",5254 // send data with fixed length

>HELLO

OK

+CIPSEND: 1,5,5

5.2.2.3 Receive Data From Server

+CIPRXGET: 1,1

// URC to notify host of data from server

AT+CIPRXGET=4,1

// query the length of data in the buffer of socket with <link_num>=1

+CIPRXGET: 4,1,16

OK

AT+CIPRXGET=2,1,5

// get data in ASCII form

+CIPRXGET: 2,1,5,11

data

```
OK
AT+CIPRXGET=3,1,5           // get data in hex form
+CIPRXGET: 3,1,5,6
66726F6D20

OK
AT+CIPRXGET=4,1             // read the length of unread data in buffer
+CIPRXGET: 4,1,6

OK
AT+CIPRXGET=2,2             // the connection identified by link_num=2 has not been established
+IP ERROR: No data

ERROR
AT+CIPRXGET=2,1
+CIPRXGET: 2,1,6,0
server

OK
AT+CIPRXGET=4,1             // all the data in buffer has been read, the rest_len is 0.
+CIPRXGET: 4,1,0

OK
```

5.2.2.4 Close UDP Connection

```
AT+CIPCLOSE=1
```

```
OK
```

```
+CIPCLOSE: 1,0
```

5.2.3 UDP Client Works in Transparent Access Mode

5.2.3.1 Set up UDP Client Connection

```
AT+CIPMODE=1
```

```
OK
```

```
AT+NETOPEN
```

```
OK
```

+NETOPEN: 0

AT+CIOPEN=0,"UDP","117.131.85.139",5254,5000

// only <link_num>=0 is allowed to operate
// with transparent mode.

CONNECT 115200

5.2.3.2 Send Data to Server

All data got from com port will be sent to internet directly

5.2.3.3 Receive Data From Server

HELLO CLIENT

// data from server output to COM port directly

HELLO CLIENT

// data from server output to COM port directly

OK

// sequence of +++ to quit transparent mode

AT+CIOPEN?

+CIOPEN: 0,"UDP","117.131.85.139",5254,-1

+CIOPEN: 1

+CIOPEN: 2

+CIOPEN: 3

+CIOPEN: 4

+CIOPEN: 5

+CIOPEN: 6

+CIOPEN: 7

+CIOPEN: 8

+CIOPEN: 9

OK

5.2.3.4 Close UDP Connection

AT+CIPCLOSE=0

CLOSED

+CIPCLOSE: 0,0

OK

5.3 TCP Server

5.3.1 Transparent Mode

```
AT+CIPMODE=1
OK
AT+NETOPEN
OK

+NETOPEN: 0

AT+SERVERSTART=8080, 0           // only <server_index>=0 is allowed to operate with
                                   // transparent mode.
OK

+CLIENT: 0,0,192.168.108.5:57202 // only <link_num> 0 can be used for transparent mode
                                   // operation.
CONNECT 115200
OK                                 // sequence of +++ to quit data mode
AT+CIPCLOSE=0                     // close client connection
OK

CLOSED

+CIPCLOSE: 0,0

AT+SERVERSTOP=0                   // close server socket
+SERVERSTOP: 0,0

OK
```

5.3.2 Non-Transparent Mode

Module supports 4 sockets to listen.

```
AT+NETOPEN
OK

+NETOPEN: 0,0
AT+SERVERSTART=8080,0
OK
AT+SERVERSTART=9090,1
OK
AT+SERVERSTART=7070,2
OK
AT+SERVERSTART=6060,3
```

OK

+CLIENT: 0,1,192.168.108.5:57202

// If a socket is accepted, this URC will be reported

AT+CIOPEN?

// User can use AT+CIOPEN? to check the
// accepted socket

+CIOPEN: 0,"TCP","192.168.108.5",57202,1

// last parameter of 1 indicates this is an accepted
// socket, this server index is 1

+CIOPEN: 1

+CIOPEN: 2

+CIOPEN: 3

+CIOPEN: 4

+CIOPEN: 5

+CIOPEN: 6

+CIOPEN: 7

+CIOPEN: 8

+CIOPEN: 9

OK

AT+CIPSEND=0,5

// only supports fixed-length to send

>HELLO

OK

+CIPSEND: 0,5,5

AT+CIPCLOSE=0

OK

+CIPCLOSE: 0,0

AT+SERVERSTOP=0

+SERVERSTOP: 0,0

OK

AT+SERVERSTOP=1

+SERVERSTOP: 1,0

OK

AT+SERVERSTOP=2

+SERVERSTOP: 2,0

OK

AT+SERVERSTOP=3

```
+SERVERSTOP: 3,0
```

```
OK
```

```
AT+NETCLOSE
```

```
OK
```

```
+NETCLOSE: 0
```

5.4 Extended Information

5.4.1 UDP Data Receiving Rules

One UDP connection could handle no more 1500 Bytes with once receiving. Please make sure that UDP server sends acceptable data packets, whose length is greater than 0 and less than 1500 Bytes.

5.5 Query Connection Status

```
AT+CIOPEN=1,"TCP","117.131.85.139",5253
```

```
OK
```

```
+CIOPEN: 1,0
```

```
AT+CIOPEN?
```

```
// query the current state of all sockets
```

```
+CIOPEN: 0
```

```
+CIOPEN: 1,"TCP","117.131.85.139",5253,-1
```

```
+CIOPEN: 2
```

```
+CIOPEN: 3
```

```
+CIOPEN: 4
```

```
+CIOPEN: 5
```

```
+CIOPEN: 6
```

```
+CIOPEN: 7
```

```
+CIOPEN: 8
```

```
+CIOPEN: 9
```

```
OK
```

```
AT+CIPCLOSE?
```

```
+CIPCLOSE: 0,1,0,0,0,0,0,0,0,0
```

```
OK
```

```
AT+CIPCLOSE=1
```

OK

+CIPCLOSE: 1,0

AT+CIPCLOSE?

+CIPCLOSE: 0,0,0,0,0,0,0,0,0,0

OK

SIMCom
Confidential